

FORM
6
Rev
05/18

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: 401985589			
Date Received:			

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: <u>100322</u>	Contact Name: <u>Brian Ulmer</u>
Name of Operator: <u>NOBLE ENERGY INC</u>	Phone: <u>(303) 905-4467</u>
Address: <u>1001 NOBLE ENERGY WAY</u>	Fax: _____
City: <u>HOUSTON</u> State: <u>TX</u> Zip: <u>77070</u>	Email: <u>brian.ulmer@nblenergy.com</u>
For "Intent" 24 hour notice required, Name: <u>Silver, Randy</u> Tel: <u>(720) 827-6688</u>	
COGCC contact: Email: <u>randy.silver@state.co.us</u>	

API Number <u>05-123-30259-00</u>	Well Name: <u>GUTTERSEN STATE D</u>	Well Number: <u>15-27</u>
Location: QtrQtr: <u>SWSE</u> Section: <u>10</u> Township: <u>3N</u> Range: <u>64W</u> Meridian: <u>6</u>		
County: <u>WELD</u>	Federal, Indian or State Lease Number: <u>70/8771</u>	
Field Name: <u>WATTENBERG</u>	Field Number: <u>90750</u>	

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.233211 Longitude: -104.532712

GPS Data:
Date of Measurement: 07/14/2010 PDOP Reading: 2.2 GPS Instrument Operator's Name: PAUL TAPPY

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____

Casing to be pulled: Yes No Estimated Depth: _____

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	6939	6952			
NIOBRARA	6676	6822			
Total: 2 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	32	641	243	641	0	VISU
1ST	7+7/8	4+1/2	11.60	7,083	690	7,083	1,841	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIPB #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 45 sks cmt from 6912 ft. to 6376 ft. Plug Type: CASING Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Perforate and squeeze at 4490 ft. with 50 sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at 2500 ft. with 35 sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at 841 ft. with 265 sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)
 Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:
 Set _____ sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Plugging Date: _____
 of _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1105 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

WE WILL BE LEAVING THE TUBING IN THE HOLE AND PUMPING CEMENT THROUGH THE TUBING. PLEASE CONTACT BRIAN ULMER WITH QUESTION ON THE PROCEDURE.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Jan Barthel
 Title: Engineering Technician Date: _____ Email: jan.barthel@nblenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

<u>COA Type</u>	<u>Description</u>

Attachment Check List

Att Doc Num

Name

401986537	WELLBORE DIAGRAM
-----------	------------------

401986538	WELLBORE DIAGRAM
-----------	------------------

Total Attach: 2 Files

General Comments

User Group

Comment

Comment Date

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)