

FORM
6Rev
05/18State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

402037829

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required.

Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120

Contact Name: CHERYL LIGHT

Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP

Phone: (720) 929-6461

Address: P O BOX 173779

Fax: (720) 929-7461

City: DENVER State: CO Zip: 80217-

Email: cheryl.light@anadarko.com

For "Intent" 24 hour notice required,

Name: Silver, Randy

Tel: (720) 827-6688

COGCC contact:

Email: randy.silver@state.co.us

API Number 05-123-32130-00

Well Name: PEAKS

Well Number: 11-2

Location: QtrQtr: SESW Section: 2 Township: 1N Range: 68W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.076589

Longitude: -104.974158

GPS Data:

Date of Measurement: 03/07/2011

PDOP Reading: 2.2

GPS Instrument Operator's Name: Renee Doiron

Reason for Abandonment:

☐ Dry☒ Production Sub-economic☐ Mechanical Problems☐ Other

Casing to be pulled:

☒ Yes☐ No

Estimated Depth: 2500

Fish in Hole:

☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks:

☐ Yes☒ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

| Formation | Perf. Top | Perf. Btm | Abandoned Date | Method of Isolation | Plug Depth |
|-----------|-----------|-----------|----------------|---------------------|------------|
| CODELL | 7832 | 7848 | | | |
| J SAND | 8275 | 8296 | | | |
| NIOBRARA | 7604 | 7712 | | | |

Total: 3 zone(s)

Casing History

| Casing Type | Size of Hole | Size of Casing | Weight Per Foot | Setting Depth | Sacks Cement | Cement Bot | Cement Top | Status |
|-------------|--------------|----------------|-----------------|---------------|--------------|------------|------------|--------|
| SURF | 12+1/4 | 8+5/8 | 24 | 925 | 580 | 925 | 0 | VISU |
| 1ST | 7+7/8 | 4+1/2 | 11.6 | 8,379 | 995 | 8,379 | 3,644 | CBL |

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 8200 with 2 sacks cmt on top. CIPB #2: Depth 7510 with 25 sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

| | | |
|---|-----------------------------|--|
| Set <u>25</u> sks cmt from <u>7510</u> ft. to <u>7100</u> ft. | Plug Type: <u>CASING</u> | Plug Tagged: <input type="checkbox"/> |
| Set <u>10</u> sks cmt from <u>4410</u> ft. to <u>4232</u> ft. | Plug Type: <u>CASING</u> | Plug Tagged: <input type="checkbox"/> |
| Set <u>50</u> sks cmt from <u>2550</u> ft. to <u>2400</u> ft. | Plug Type: <u>STUB PLUG</u> | Plug Tagged: <input type="checkbox"/> |
| Set <u>50</u> sks cmt from <u>150</u> ft. to <u>0</u> ft. | Plug Type: <u>CASING</u> | Plug Tagged: <input checked="" type="checkbox"/> |
| Set _____ sks cmt from _____ ft. to _____ ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 95 sacks half in. half out surface casing from 1025 ft. to 875 ft. Plug Tagged: ☐

Set 50 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: CHERYL LIGHT

Title: Staff Regulatory Analyst Date: _____ Email: DJREGULATORY@ANADARKO.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: _____

COA Type

Description

| | |
|--|--|
| | |
|--|--|

Attachment Check List

Att Doc Num

Name

| | |
|-----------|-----------------------------|
| 402038564 | PROPOSED PLUGGING PROCEDURE |
| 402038565 | WELLBORE DIAGRAM |

Total Attach: 2 Files

General Comments

User Group

Comment

Comment Date

| | | |
|--|--|---------------------|
| | | Stamp Upon Approval |
|--|--|---------------------|

Total: 0 comment(s)