

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

Document Number:  
402455533

Date Received:

OGCC Operator Number: 10633 Contact Name: Cole Carveth

Name of Operator: CRESTONE PEAK RESOURCES OPERATING LLC Phone: (303) 774-3979

Address: 1801 CALIFORNIA STREET #2500 Fax: \_\_\_\_\_

City: DENVER State: CO Zip: 80202 Email: cole.carveth@crestonepr.com

**For "Intent" 24 hour notice required,** Name: Sherman, Susan Tel: (719) 775-1111

**COGCC contact:** Email: susan.sherman@state.co.us

Type of Well Abandonment Report:  Notice of Intent to Abandon  Subsequent Report of Abandonment

API Number 05-005-06203-00

Well Name: AMOCO-WESTAN- Well Number: 1

Location: QtrQtr: NENE Section: 8 Township: 4S Range: 64W Meridian: 6

County: ARAPAHOE Federal, Indian or State Lease Number: \_\_\_\_\_

Field Name: WILDCAT Field Number: 99999

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 39.722964 Longitude: -104.567020

GPS Data: GPS Quality Value: \_\_\_\_\_ Type of GPS Quality Value: \_\_\_\_\_ Date of Measurement: \_\_\_\_\_

GPS Instrument Operator's Name: \_\_\_\_\_

Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems

Other Re-plug well to provide proper isolation for offset mitigation for the

Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_

Fish in Hole:  Yes  No If yes, explain details below

Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below

Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	214	230	214	0	VISU

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set	150	sks cmt from	7400	ft. to	6900	ft.	Plug Type: OPEN HOLE	Plug Tagged: <input type="checkbox"/>
Set	125	sks cmt from	3200	ft. to	3000	ft.	Plug Type: OPEN HOLE	Plug Tagged: <input type="checkbox"/>
Set	290	sks cmt from	1900	ft. to	1400	ft.	Plug Type: OPEN HOLE	Plug Tagged: <input checked="" type="checkbox"/>
Set	400	sks cmt from	1400	ft. to	700	ft.	Plug Type: OPEN HOLE	Plug Tagged: <input checked="" type="checkbox"/>
Set	_____	sks cmt from	_____	ft. to	_____	ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set 350 sacks half in. half out surface casing from 700 ft. to 0 ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. \_\_\_\_\_ inch casing Cut and Cap Date: \_\_\_\_\_  
of  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1105  Yes  No

Technical Detail/Comments:

Proposed plugging procedure is attached.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Jane Washburn  
 Title: Sr Prod Engineering Tech Date: \_\_\_\_\_ Email: jane.washburn@crestonepr.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: \_\_\_\_\_

COA Type	Description

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
402455683	PROPOSED PLUGGING PROCEDURE
402455684	WELLBORE DIAGRAM
402455685	WELLBORE DIAGRAM
402456745	SURFACE OWNER CONSENT
402456747	LOCATION PHOTO

Total Attach: 5 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)