

Document Number:
 402572529

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10633 Contact Name: Cole Carveth
 Name of Operator: CRESTONE PEAK RESOURCES OPERATING LLC Phone: (303) 7743979
 Address: 1801 CALIFORNIA STREET #2500 Fax: _____
 City: DENVER State: CO Zip: 80202 Email: cole.carveth@crestonepr.com

For "Intent" 24 hour notice required, Name: Silver, Randy Tel: (720) 827-6688
COGCC contact: Email: randy.silver@state.co.us

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number 05-013-06540-00
 Well Name: MCDONALD Well Number: 34-25
 Location: QtrQtr: SWSE Section: 25 Township: 2N Range: 69W Meridian: 6
 County: BOULDER Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.104840 Longitude: -105.063120
 GPS Data: GPS Quality Value: 3.6 Type of GPS Quality Value: PDOP Date of Measurement: 07/07/2007

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____

Casing to be pulled: Yes No Estimated Depth: 2000
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

| Formation | Perf. Top | Perf. Btm | Abandoned Date | Method of Isolation | Plug Depth |
|-----------|-----------|-----------|----------------|---------------------|------------|
| CODELL | 7598 | 7618 | | | |
| J SAND | 8038 | 8054 | | | |
| NIOBRARA | 7364 | 7384 | | | |

Total: 3 zone(s)

Casing History

| Casing Type | Size of Hole | Size of Casing | Grade | Wt/Ft | Csg/Liner Top | Setting Depth | Sacks Cmt | Cmt Btm | Cmt Top | Status |
|-------------|--------------|----------------|-------|------------|---------------|---------------|-----------|---------|---------|--------|
| SURF | 12+1/4 | 8+5/8 | J-55 | 24 | 0 | 788 | 380 | 788 | 0 | CALC |
| 1ST | 7+7/8 | 4+1/2 | I-80 | 11.6 | 0 | 8149 | 250 | 8149 | 6740 | CBL |
| | | | | Stage Tool | | 5160 | 340 | 5160 | 3890 | CBL |

Subsurface hazards include, but are not limited to, the following: overpressured zones, underpressured zones, major geologic faults, salt sections, H2S at concentrations greater than or equal to 100 ppm.

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7980 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 15 sks cmt from 7300 ft. to 7103 ft. Plug Type: CASING Plug Tagged:
 Set 10 sks cmt from 5215 ft. to 5083 ft. Plug Type: CASING Plug Tagged:
 Set 15 sks cmt from 4290 ft. to 4093 ft. Plug Type: CASING Plug Tagged:
 Set 75 sks cmt from 2000 ft. to 1800 ft. Plug Type: STUB PLUG Plug Tagged:
 Set 155 sks cmt from 500 ft. to 0 ft. Plug Type: CASING Plug Tagged:
 Perforate and squeeze at 7364 ft. with 100 sacks. Leave at least 100 ft. in casing 7300 CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 (Cast Iron Cement Retainer Depth)

Set 120 sacks half in. half out surface casing from 840 ft. to 500 ft. Plug Tagged:
 Set _____ sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____
 Surface Plug Setting Date: _____ Cut and Cap Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Katelyn Davis
 Title: Engineering Tech Date: _____ Email: katelyn.davis@crestonepr.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

| <u>COA Type</u> | <u>Description</u> |
|-----------------|--------------------|
| | |

Attachment Check List

| <u>Att Doc Num</u> | <u>Name</u> |
|--------------------|------------------|
| 402572547 | WELLBORE DIAGRAM |

Total Attach: 1 Files

General Comments

| <u>User Group</u> | <u>Comment</u> | <u>Comment Date</u> |
|-------------------|----------------|---------------------|
| | | Stamp Upon Approval |

Total: 0 comment(s)