

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

Document Number:  
 403272661  
 Date Received:  
 12/28/2022

OGCC Operator Number: 10633 Contact Name: Adam Conry  
 Name of Operator: CRESTONE PEAK RESOURCES OPERATING LLC Phone: (303) 883-3351  
 Address: 1801 CALIFORNIA STREET #2500 Fax: \_\_\_\_\_  
 City: DENVER State: CO Zip: 80202 Email: AConry@civiresources.com

**For "Intent" 24 hour notice required,** Name: Medina, Justin Tel: (720) 471-0006  
**COGCC contact:** Email: justin.medina@state.co.us

Type of Well Abandonment Report:  Notice of Intent to Abandon  Subsequent Report of Abandonment

API Number 05-001-05050-00  
 Well Name: MCVEY Well Number: 1  
 Location: QtrQtr: NWNW Section: 17 Township: 3S Range: 65W Meridian: 6  
 County: ADAMS Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WILDCAT Field Number: 99999

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 39.796402 Longitude: -104.694594  
 GPS Data: GPS Quality Value: \_\_\_\_\_ Type of GPS Quality Value: Accuracy in Meters Date of Measurement: 11/03/1958  
 Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems  
 Other Re-Entry P&A  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	13+1/2	8+5/8	na	24	0	163	150	163	0	CALC
OPEN HOLE	7+7/8				163	8476				

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 225 sks cmt from 7700 ft. to 7100 ft. Plug Type: OPEN HOLE Plug Tagged:   
Set 125 sks cmt from 1900 ft. to 1600 ft. Plug Type: OPEN HOLE Plug Tagged:   
Set 420 sks cmt from 1300 ft. to 163 ft. Plug Type: OPEN HOLE Plug Tagged:   
Set 250 sks cmt from 163 ft. to 0 ft. Plug Type: CASING Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)  
Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
Set \_\_\_\_\_ sacks at surface  
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: \_\_\_\_\_  
Surface Plug Setting Date: \_\_\_\_\_ Cut and Cap Date: \_\_\_\_\_  
\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
Type of Cement and Additives Used: \_\_\_\_\_  
Flowline/Pipeline has been abandoned per Rule 1105  Yes  No

Technical Detail/Comments:

PROPOSED WBD ATTACHED  
Not in HPH (No CPW consult attached)

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Ashley Noonan  
Title: Sr. Regulatory Analyst Date: 12/28/2022 Email: regulatory@civiresources.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Jacobson, Eric Date: 1/4/2023

**CONDITIONS OF APPROVAL, IF ANY:**

Expiration Date: 7/3/2023

<b>COA Type</b>	<b>Description</b>
	1) Provide electronic Form 42 Notice of MIRU 2 business days ahead of operations and electronic Form 42 Notice of Plugging Operations 48 hours prior to mobilizing for plugging operations. 2) Prior to placing the 1300' plug: verify that all fluid (liquid and gas) migration has been eliminated. If evidence of fluid migration or pressure remains, contact COGCC Engineer for an update to plugging orders. 3) After isolation has been verified, pump surface casing shoe plug. If cement is not circulated to surface, shut-in, WOC 4 hours then tag plug – must be at 163' or shallower and provide 10 sx plug at the surface. 4) Leave at least 100' of cement in the wellbore for each plug without mechanical isolation. 5) With the Form 6 SRA operator must provide written documentation which positively affirms each COA listed above has been addressed.
	Submit "as drilled" GPS data on Subsequent Report of Abandonment. GPS data must meet the requirements of Rule 216.
2 COAs	

### Attachment List

<b>Att Doc Num</b>	<b>Name</b>
403272661	FORM 6 INTENT SUBMITTED
403272662	WELLBORE DIAGRAM

Total Attach: 2 Files

### General Comments

<b>User Group</b>	<b>Comment</b>	<b>Comment Date</b>
Engineer	Well file verification not completed prior to approval of NOIA.	01/04/2023
Engineer	Deepest Water Well within 1 Mile – 30' SB5 Base of Fox Hills - 1843' SB5 Base of Lower Arapahoe - 1258' SB5 Base of Upper Arapahoe - 961' SB5 Base of Denver - 681'  Denver / 4769 / 5242 / 174.4 / 681 / 208 / 47.44NNT Upper Arapahoe / 4489 / 4744 / 96.3 / 961 / 706 / 26.19NT Lower Arapahoe / 4192 / 4414 / 108.2 / 1258 / 1036 / 29.43NT Laramie-Fox Hills / 3607 / 3836 / 164.3 / 1843 / 1614 / 39.43NT	01/04/2023
Permit	Reviewed WBDs. Pass.	12/28/2022
OGLA	OGLA review is complete.	12/28/2022

Total: 4 comment(s)