

<b>FORM</b> 6 Rev 11/20	<b>State of Colorado</b> <b>Oil and Gas Conservation Commission</b>				DE	ET	OE	ES																																				
	1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109				Document Number:  403455815  Date Received:																																							
<b>WELL ABANDONMENT REPORT</b>																																												
<p>This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.</p> <p>A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.</p>																																												
OGCC Operator Number: <u>47120</u>					Contact Name: <u>Candice Barber</u>																																							
Name of Operator: <u>KERR MCGEE OIL &amp; GAS ONSHORE LP</u>					Phone: <u>(307) 2334513</u>																																							
Address: <u>P O BOX 173779</u>					Fax: _____																																							
City: <u>DENVER</u>		State: <u>CO</u>		Zip: <u>80217-</u>		Email: <u>candice_barber@oxy.com</u>																																						
<table style="width:100%;"> <tr> <td style="width:30%;"> <b>For "Intent" 24 hour notice required,</b> </td> <td style="width:30%;">           Name: _____         </td> <td style="width:30%;">           Tel: _____         </td> </tr> <tr> <td> <b>COGCC contact:</b> </td> <td colspan="2">           Email: _____         </td> </tr> </table>									<b>For "Intent" 24 hour notice required,</b>	Name: _____	Tel: _____	<b>COGCC contact:</b>	Email: _____																															
<b>For "Intent" 24 hour notice required,</b>	Name: _____	Tel: _____																																										
<b>COGCC contact:</b>	Email: _____																																											
Type of Well Abandonment Report: <input type="checkbox"/> Notice of Intent to Abandon <input checked="" type="checkbox"/> Subsequent Report of Abandonment																																												
<table style="width:100%;"> <tr> <td colspan="3">           API Number <u>05-123-31085-00</u> </td> <td colspan="3">           Well Name: <u>BERRY P</u> </td> <td colspan="3">           Well Number: <u>08-18D</u> </td> </tr> <tr> <td>           Location:         </td> <td>           QtrQtr: <u>NENW</u> </td> <td>           Section: <u>8</u> </td> <td>           Township: <u>3N</u> </td> <td>           Range: <u>67W</u> </td> <td>           Meridian: <u>6</u> </td> <td colspan="3"></td> </tr> <tr> <td colspan="3">           County: <u>WELD</u> </td> <td colspan="6">           Federal, Indian or State Lease Number: _____         </td> </tr> <tr> <td colspan="3">           Field Name: <u>WATTENBERG</u> </td> <td colspan="6">           Field Number: <u>90750</u> </td> </tr> </table>									API Number <u>05-123-31085-00</u>			Well Name: <u>BERRY P</u>			Well Number: <u>08-18D</u>			Location:	QtrQtr: <u>NENW</u>	Section: <u>8</u>	Township: <u>3N</u>	Range: <u>67W</u>	Meridian: <u>6</u>				County: <u>WELD</u>			Federal, Indian or State Lease Number: _____						Field Name: <u>WATTENBERG</u>			Field Number: <u>90750</u>					
API Number <u>05-123-31085-00</u>			Well Name: <u>BERRY P</u>			Well Number: <u>08-18D</u>																																						
Location:	QtrQtr: <u>NENW</u>	Section: <u>8</u>	Township: <u>3N</u>	Range: <u>67W</u>	Meridian: <u>6</u>																																							
County: <u>WELD</u>			Federal, Indian or State Lease Number: _____																																									
Field Name: <u>WATTENBERG</u>			Field Number: <u>90750</u>																																									
<i>Only Complete the Following Background Information for Intent to Abandon</i>																																												
Latitude: <u>40.246416</u>			Longitude: <u>-104.915871</u>																																									
GPS Data:    GPS Quality Value: <u>1.4</u>			Type of GPS Quality Value: <u>PDOP</u>			Date of Measurement: <u>06/07/2023</u>																																						
Reason for Abandonment: <input type="checkbox"/> Dry <input type="checkbox"/> Production Sub-economic <input type="checkbox"/> Mechanical Problems <input type="checkbox"/> Other _____																																												
Casing to be pulled: <input type="checkbox"/> Yes <input type="checkbox"/> No			Estimated Depth: _____																																									
Fish in Hole: <input type="checkbox"/> Yes <input type="checkbox"/> No			If yes, explain details below																																									
Wellbore has Uncemented Casing leaks: <input type="checkbox"/> Yes <input type="checkbox"/> No			If yes, explain details below																																									
Details: _____																																												
<b>Current and Previously Abandoned Zones</b>																																												
<table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Formation</th> <th style="text-align: center;">Perf. Top</th> <th style="text-align: center;">Perf. Btm</th> <th style="text-align: center;">Abandoned Date</th> <th style="text-align: left;">Method of Isolation</th> <th style="text-align: center;">Plug Depth</th> </tr> </thead> <tbody> <tr> <td>CODELL</td> <td style="text-align: center;">7262</td> <td style="text-align: center;">7278</td> <td style="text-align: center;">03/14/2023</td> <td>B PLUG CEMENT TOP</td> <td style="text-align: center;">6934</td> </tr> <tr> <td>NIOBRARA</td> <td style="text-align: center;">7052</td> <td style="text-align: center;">7148</td> <td style="text-align: center;">03/14/2023</td> <td>B PLUG CEMENT TOP</td> <td style="text-align: center;">6934</td> </tr> </tbody> </table>									Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth	CODELL	7262	7278	03/14/2023	B PLUG CEMENT TOP	6934	NIOBRARA	7052	7148	03/14/2023	B PLUG CEMENT TOP	6934																		
Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth																																							
CODELL	7262	7278	03/14/2023	B PLUG CEMENT TOP	6934																																							
NIOBRARA	7052	7148	03/14/2023	B PLUG CEMENT TOP	6934																																							
Total: 2 zone(s)																																												
<b>Casing History</b>																																												
<table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Casing Type</th> <th style="text-align: center;">Size of Hole</th> <th style="text-align: center;">Size of Casing</th> <th style="text-align: center;">Grade</th> <th style="text-align: center;">Wt/Ft</th> <th style="text-align: center;">Csg/Liner Top</th> <th style="text-align: center;">Setting Depth</th> <th style="text-align: center;">Sacks Cmt</th> <th style="text-align: center;">Cmt Btm</th> <th style="text-align: center;">Cmt Top</th> <th style="text-align: left;">Status</th> </tr> </thead> <tbody> <tr> <td>SURF</td> <td style="text-align: center;">12+1/4</td> <td style="text-align: center;">8+5/8</td> <td style="text-align: center;">J-55</td> <td style="text-align: center;">24</td> <td style="text-align: center;">0</td> <td style="text-align: center;">487</td> <td style="text-align: center;">188</td> <td style="text-align: center;">457</td> <td style="text-align: center;">0</td> <td style="text-align: left;">VISU</td> </tr> <tr> <td>1ST</td> <td style="text-align: center;">7+7/8</td> <td style="text-align: center;">4+1/2</td> <td style="text-align: center;">M-80</td> <td style="text-align: center;">11.6</td> <td style="text-align: center;">0</td> <td style="text-align: center;">7436</td> <td style="text-align: center;">600</td> <td style="text-align: center;">7436</td> <td style="text-align: center;">2200</td> <td style="text-align: left;">CBL</td> </tr> </tbody> </table>									Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status	SURF	12+1/4	8+5/8	J-55	24	0	487	188	457	0	VISU	1ST	7+7/8	4+1/2	M-80	11.6	0	7436	600	7436	2200	CBL			
Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status																																		
SURF	12+1/4	8+5/8	J-55	24	0	487	188	457	0	VISU																																		
1ST	7+7/8	4+1/2	M-80	11.6	0	7436	600	7436	2200	CBL																																		

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6934 with 2 sacks cmt on top. CIBP #2: Depth 260 with 93 sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 93 sks cmt from 260 ft. to 10 ft. Plug Type: STUB PLUG Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at 4081 ft. with 100 sacks. Leave at least 100 ft. in casing 4051 CICR Depth  
Perforate and squeeze at 2480 ft. with 100 sacks. Leave at least 100 ft. in casing 2450 CICR Depth  
Perforate and squeeze at 1470 ft. with 325 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 120 sacks half in. half out surface casing from 623 ft. to 281 ft. Plug Tagged: ☒

Set 1 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: 1500 ft. of 4+1/2 inch casing

Surface Plug Setting Date: 03/22/2023 Cut and Cap Date: 06/06/2023 Number of Days from Setting Surface Plug to Capping or Sealing the Well: 76

\*Wireline Contractor: RANGER

\*Cementing Contractor: RANGER

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1105 ☒ Yes ☐ No

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_

Print Name: Candice Barber

Title: REGULATORY ANALYST

Date: \_\_\_\_\_

Email: DJREGULATORY@OXY.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_

Date: \_\_\_\_\_

### CONDITIONS OF APPROVAL, IF ANY:

#### COA Type

#### Description

0 COA	

### **Attachment List**

<b><u>Att Doc Num</u></b>	<b><u>Name</u></b>
403457452	OPERATIONS SUMMARY
403457453	OTHER
403457455	CEMENT JOB SUMMARY
403457456	OTHER
403457457	WELLBORE DIAGRAM
403457459	WIRELINE JOB SUMMARY

Total Attach: 6 Files

### **General Comments**

<b><u>User Group</u></b>	<b><u>Comment</u></b>	<b><u>Comment Date</u></b>
		Stamp Upon Approval

Total: 0 comment(s)