

OGCC FORM 4
OIL AND GAS CONSERVATION COMMISSION
 DEPARTMENT OF NATURAL RESOURCES
 OF THE STATE OF COLORADO

RECEIVED

JUL 22 1974

File in duplicate for Patented and Federal lands.
 File in triplicate for State lands.

COLORADO OIL & GAS CONSERVATION COMMISSION



00046193

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
 Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> <u>WATER INJECTION WELL</u>		5. LEASE DESIGNATION AND SERIAL NO. <u>PATENTED</u>
2. NAME OF OPERATOR <u>CHEVRON OIL CO, WESTERN DIVISION</u>		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR <u>RANGELY, COLORADO 81648</u>		7. UNIT AGREEMENT NAME <u>RANGELY WEBER SAND</u>
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface <u>2406' SNL; 1416' EWL OF SEC. 2, T1N, R102W,</u> <u>At proposed prod. zone</u> <u>SE NW 6th P.M.</u>		8. FARM OR LEASE NAME <u>C. S. HEFLEY</u>
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) <u>DF - 5227</u>	9. WELL NO. <u>2</u>
16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data		10. FIELD AND POOL, OR WILDCAT <u>RANGELY WEBER SAND</u>
NOTICE OF INTENTION TO: TEST WATER SHUT-OFF <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> FRACTURE TREAT <input type="checkbox"/> MULTIPLE COMPLETE <input type="checkbox"/> SHOOT OR ACIDIZE <input type="checkbox"/> ABANDON <input checked="" type="checkbox"/> REPAIR WELL <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> (Other) <input type="checkbox"/>		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA <u>SEC 2</u> <u>T1N, R102W</u>
		12. COUNTY <u>RIOBLANCO</u>
		13. STATE <u>COLO.</u>

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Date of work AFTER AUGUST 1, 1974

It is proposed to plug and abandon this well as follows:

1. Rig up and pull tubing.
2. Set 100' cement plug through a retainer, set +50' above 7" casing shoe.
3. Set a 2-3 sacks cement plug on top of the retainer.
4. Pump 150 sacks cement down the 7"-surface pipe annulus.
5. Lay a 30' cement plug in the top of the 7" casing.
6. Weld a plate over casing head and install marker.
7. Remove or bury cement pumping unit foundation and "dead men".
8. Clean up all loose pipe, fittings, debris, etc. from location.
9. Scarify non grassy areas and plant seed (8-10#/acre), avoid further disturbance of surface conditions.

DVR	
FJP	
NHM	
JAN	✓
JJD	✓
GCH	
CGM	

18. I hereby certify that the foregoing is true and correct

SIGNED J. A. THOMPSON TITLE UNIT SUPT. DATE 7-19-74

(This space for Federal or State office use)

APPROVED BY [Signature] TITLE DIRECTOR DATE JUL 24 1974

CONDITIONS OF APPROVAL, IF ANY: