

OIL AND GAS CONSERVATION COMMISSION DEPARTMENT OF NATURAL RESOURCES OF THE STATE OF COLORADO

JUL 22 1974



00596193

File in duplicate for Patented and Federal lands.
File in triplicate for State lands.

COLD OIL & GAS CONS.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> WATER INJECTION WELL		5. LEASE DESIGNATION AND SERIAL NO. COMM. <u>PATENTED</u>	
2. NAME OF OPERATOR <u>CHEVRON OIL CO, WESTERN DIVISION</u>		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR <u>RANGELY, COLORADO 81648</u>		7. UNIT AGREEMENT NAME <u>RANGELY WEBER SAND</u>	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface <u>2012' NSL 759' EWL OF SEC. 2, T1N, R102W,</u> At proposed prod. zone <u>NW SW 6th P.M.</u>		8. FARM OR LEASE NAME <u>C.S. HEFLEY</u>	
14. PERMIT NO.		9. WELL NO. <u>3</u>	
15. ELEVATIONS (Show whether DF, RT, GB, etc.) <u>RT - 5247</u>		10. FIELD AND POOL, OR WILDCAT <u>RANGELY WEBER SAND</u>	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA <u>SEC. 2 T1N, R102W</u>	
		12. COUNTY <u>RIO BLANCO</u>	
		13. STATE <u>COLO</u>	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Date of work

AFTER AUGUST 1, 1974

It is proposed to plug and abandon this well as follows:

1. Rig up and pull tubing.
2. Set 100' cement plug through a retainer, set +50' above 7" casing shoe.
3. Set a 2-3 sacks cement plug on top of the retainer.
4. Pump 150 sacks cement down the 7"-surface pipe annulus.
5. Lay a 30' cement plug in the top of the 7" casing.
6. Weld a plate over casing head and install marker.
7. Remove or bury cement pumping unit foundation and "dead men".
8. Clean up all loose pipe, fittings, debris, etc. from location.
9. Scarify non grassy areas and plant seed (8-10#/acre), avoid further disturbance of surface conditions.

DVR	
EJP	
HHM	
JAM	✓
JJD	✓
GCH	
CGM	

18. I hereby certify that the foregoing is true and correct

SIGNED

J.A. THOMPSON

TITLE

UNIT SUPT.

DATE

7-19-74

(This space for Federal or State office use)

APPROVED BY

McRae

TITLE

DIRECTOR

U.S. & CAN. COM.

DATE

JUL 24 1974

CONDITIONS OF APPROVAL, IF ANY: