

OIL AND GAS CONSERVATION COMMISSION DEPARTMENT OF NATURAL RESOURCES OF THE STATE OF COLORADO

File in duplicate for Patented and Federal lands.
File in triplicate for State lands.

COLO. OIL & GAS CONS. COMM.

RECEIVED

APR 27 1981



SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO.	
2. NAME OF OPERATOR J & L Oil Corporation		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR Rt. 4, 17566 Rd. 30, Sterling, Colorado 80751		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface SE NW NW 2073 T1W1 & 668 T1W1		8. FARM OR LEASE NAME Padroni	
At proposed prod. zone same		9. WELL NO. 1	
14. PERMIT NO.		10. FIELD AND POOL, OR WILDCAT Cayuse	
15. ELEVATIONS (Show whether DF, RT, GR, etc.)		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 30-9N-52W	
		12. COUNTY Logan	13. STATE Colo.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐

REPAIRING WELL

☐
☐
☐

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Date of work as soon as possible - approx. 30 days

Application to plug as follows:

Run sand on top of and above casing perforations

Put 5 sacks cement on top of sand

Put 20 sacks cement in and out bottom of surface casing

Also 10 sacks cement in top of surface casing

Weld plate on top of surface casing 3 feet below ground level

DVR	
FJR	
HHM	
JAN	
JJD	
RLS	
COM	

18. I hereby certify that the foregoing is true and correct

SIGNED

John H. Swenko

TITLE

President

DATE

April 24, 1981

(This space for Federal or State office use)

APPROVED BY

W. Rogers

TITLE

DIRECTOR
O & G Cons. Comm.

DATE

APR 28 1981

CONDITIONS OF APPROVAL, IF ANY: