



<div>FORM</div> <div>6</div> <div>Rev 11/20</div>	<div>State of Colorado</div> <div>Energy & Carbon Management Commission</div> <div>1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109</div>	<div></div>	<table><tr><td>DE</td><td>ET</td><td>OE</td><td>ES</td></tr></table>	DE	ET	OE	ES																													
	DE	ET	OE	ES																																
<div>WELL ABANDONMENT REPORT</div> <div><p>This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.</p></div>			<div>Replug By Other Operator</div> <div>Document Number: 403947739</div> <div>Date Received:</div>																																	
<div><div>ECMC Operator Number: 10819</div><div>Contact Name: Venessa Chase</div><div>Name of Operator: PRAIRIE OPERATING CO LLC</div><div>Phone: (303) 907-1714</div><div>Address: 50 S STEELE STREET SUITE 450</div><div>Fax:</div><div>City: DENVER State: CO Zip: 80209</div><div>Email: vc@prairieopco.com</div><div>For "Intent" 24 hour notice required, Name: Petrie, Erica Tel: (303) 726-3822</div><div>ECMC contact: Email: erica.petrie@state.co.us</div></div>																																				
<div>Type of Well Abandonment Report: <input checked="" type="checkbox"/> Notice of Intent to Abandon <input type="checkbox"/> Subsequent Report of Abandonment</div>																																				
<div><div>API Number 05-123-09370-00</div><div>Well Name: WEITZEL Well Number: 8-3</div><div>Location: QtrQtr: SWNW Section: 8 Township: 7N Range: 60W Meridian: 6</div><div>County: WELD Federal, Indian or State Lease Number:</div><div>Field Name: MORNINGSIDE Field Number: 56000</div></div>																																				
<div>Only Complete the Following Background Information for Intent to Abandon</div> <div><div>Latitude: 40.591325 Longitude: -104.123973</div><div>GPS Data: GPS Quality Value: 2.2 Type of GPS Quality Value: PDOP Date of Measurement: 08/20/2024</div><div>Reason for Abandonment: <input type="checkbox"/> Dry <input type="checkbox"/> Production Sub-economic <input type="checkbox"/> Mechanical Problems</div><div><input checked="" type="checkbox"/> Other Re-Enter to Re-Plug</div><div>Casing to be pulled: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No Estimated Depth:</div><div>Fish in Hole: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No If yes, explain details below</div><div>Wellbore has Uncemented Casing leaks: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No If yes, explain details below</div><div>Details:</div></div>																																				
<div>Current and Previously Abandoned Zones</div> <table><tr><th>Formation</th><th>Perf. Top</th><th>Perf. Btm</th><th>Abandoned Date</th><th>Method of Isolation</th><th>Plug Depth</th></tr><tr><td>J SAND</td><td>6972</td><td>6992</td><td>11/10/1978</td><td>CEMENT</td><td>6950</td></tr></table> <div>Total: 1 zone(s)</div>				Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth	J SAND	6972	6992	11/10/1978	CEMENT	6950																					
Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth																															
J SAND	6972	6992	11/10/1978	CEMENT	6950																															
<div>Casing History</div> <table><tr><th>Casing Type</th><th>Size of Hole</th><th>Size of Casing</th><th>Grade</th><th>Wt/Ft</th><th>Csg/Liner Top</th><th>Setting Depth</th><th>Sacks Cmt</th><th>Cmt Btm</th><th>Cmt Top</th><th>Status</th></tr><tr><td>SURF</td><td>12+1/4</td><td>8+5/8</td><td>J55</td><td>24</td><td>0</td><td>259</td><td>190</td><td></td><td></td><td></td></tr><tr><td>1ST</td><td>7+7/8</td><td>4+1/2</td><td>J55</td><td>10.5</td><td>5930</td><td>7004</td><td>125</td><td></td><td></td><td></td></tr></table>				Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status	SURF	12+1/4	8+5/8	J55	24	0	259	190				1ST	7+7/8	4+1/2	J55	10.5	5930	7004	125			
Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status																										
SURF	12+1/4	8+5/8	J55	24	0	259	190																													
1ST	7+7/8	4+1/2	J55	10.5	5930	7004	125																													

Date Run: 10/7/2024 Doc [#403947739] Well Name: WEITZEL 8-3

Page 1 of 3

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 145 sks cmt from 2000 ft. to 1500 ft. Plug Type: OPEN HOLE Plug Tagged: ☒
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Perforate and squeeze at 6300 ft. with 120 sacks. Leave at least 100 ft. in casing 6200 CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set 175 sacks half in. half out surface casing from 550 ft. to 0 ft. Plug Tagged: ☐
Set _____ sacks at surface
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No
Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____
Surface Plug Setting Date: _____ Cut and Cap Date: _____
*Wireline Contractor: _____ *Cementing Contractor: _____
Type of Cement and Additives Used: _____
Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

See Proposed Plugging Procedure attached.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Venessa Chase
Title: Manager of Reg Affairs Date: _____ Email: vc@prairieopco.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with ECMC Rules and applicable orders and is hereby approved.

ECMC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY LIST

Expiration Date: _____

COA Type	Description
0 COA	

ATTACHMENT LIST

<u>Att Doc Num</u>	<u>Name</u>
403947758	WELLBORE DIAGRAM
403947759	PROPOSED PLUGGING PROCEDURE
403947760	LOCATION PHOTO
403947761	SURFACE OWNER CONSENT

Total Attach: 4 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)