

Replug By Other Operator

Document Number:
404348826

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

ECMC Operator Number: 10711 Contact Name: Deborah Abrams

Name of Operator: PAINTED PEGASUS PETROLEUM LLC Phone: (303) 8942100

Address: 16820 BARKER SPRINGS RD #521 Fax: _____

City: HOUSTON State: TX Zip: 77084 Email: deborah.abrams@state.co.us

For "Intent" 24 hour notice required, Name: Medina, Justin Tel: (720) 471-0006

ECMC contact: Email: justin.medina@state.co.us

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number 05-001-09197-00

Well Name: HSR GREGG Well Number: 15-10 (OWP)

Location: QtrQtr: SWSE Section: 10 Township: 2S Range: 64W Meridian: 6

County: ADAMS Federal, Indian or State Lease Number: _____

Field Name: JAMBOREE Field Number: 40590

Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.886709 Longitude: -104.532577

GPS Data: GPS Quality Value: 2.5 Type of GPS Quality Value: _____ Date of Measurement: 10/26/2010

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems

Other OWP

Casing to be pulled: Yes No Estimated Depth: _____

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
J SAND	7902	7928			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	UNK	24	0	445	315	445	0	VISU
1ST	7+7/8	4+1/2	UNK	11.6	0	8039	250	8039	6560	CBL
S.C. 1.1	7+7/8	4+1/2				1638	300	1638	350	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7827 with 2 sacks cmt on top. CIBP #2: Depth 6975 with 2 sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 40 sks cmt from 1561 ft. to 1189 ft. Plug Type: CASING Plug Tagged:
Set 40 sks cmt from 697 ft. to 308 ft. Plug Type: CASING Plug Tagged:
Set 75 sks cmt from 258 ft. to 0 ft. Plug Type: ANNULUS Plug Tagged:
Set 25 sks cmt from 258 ft. to 0 ft. Plug Type: CASING Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at 2550 ft. with 50 sacks. Leave at least 100 ft. in casing 2500 CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:
Set _____ sacks at surface
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____
Surface Plug Setting Date: _____ Cut and Cap Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

Stage cement sacks is calculated. Number of sacks was not reported.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Deborah Abrams
Title: OWP Date: _____ Email: deborah.abrams@state.co.us

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with ECMC Rules and applicable orders and is hereby approved.

ECMC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY LIST

Expiration Date: _____

COA Type	Description
0 COA	

ATTACHMENT LIST

Att Doc Num	Name
404348871	WELLBORE DIAGRAM

Total Attach: 1 Files

General Comments

User Group	Comment	Comment Date
		Stamp Upon Approval

Total: 0 comment(s)