

Document Number:
 404395120
 Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

ECMC Operator Number: 92950 Contact Name: Bill Wade
 Name of Operator: VAUGHEY & VAUGHEY Phone: (720) 916-8603
 Address: 1840 CAPITOL TOWERS Fax: _____
 City: JACKSON State: MS Zip: 39201- Email: bill.wade@state.co.us

For "Intent" 24 hour notice required, Name: Labowskie, Steve Tel: (970) 946-5073
 Email: steve.labowskie@state.co.us
ECMC contact:

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number 05-083-05149-00
 Well Name: G L VEACH Well Number: 1 (OWP)
 Location: QtrQtr: NENW Section: 3 Township: 34N Range: 20W Meridian: N
 County: MONTEZUMA Federal, Indian or State Lease Number: _____
 Field Name: WILDCAT Field Number: 99999

Only Complete the Following Background Information for Intent to Abandon

Latitude: 37.238379 Longitude: -109.037343
 GPS Data: GPS Quality Value: _____ Type of GPS Quality Value: _____ Date of Measurement: _____
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other OWP Well
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
ENTRADA	910	930			
Total: 1 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	17+1/2	13+3/8	N/A	48		387	300	387	0	CALC
1ST	12+0/1	9+5/8	N/A	32.3		1435	1000	1435	0	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set	50	sks cmt from	660	ft. to	560	ft.	Plug Type: CASING	Plug Tagged: <input type="checkbox"/>
Set	50	sks cmt from	437	ft. to	337	ft.	Plug Type: CASING	Plug Tagged: <input checked="" type="checkbox"/>
Set		sks cmt from		ft. to		ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>
Set		sks cmt from		ft. to		ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>
Set		sks cmt from		ft. to		ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>

Perforate and squeeze at 910 ft. with 50 sacks. Leave at least 100 ft. in casing 900 CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:
 Set 50 sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing
 Surface Plug Setting Date: _____ Cut and Cap Date: _____ Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Bill Wade
 Title: OWP field specialist Date: _____ Email: bill.wade@state.co.us

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with ECMC Rules and applicable orders and is hereby approved.

ECMC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY LIST

Expiration Date: _____

<u>COA Type</u>	<u>Description</u>
0 COA	

ATTACHMENT LIST

<u>Att Doc Num</u>	<u>Name</u>
404395379	WELLBORE DIAGRAM

Total Attach: 1 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)