

Replug By Other Operator

Document Number:

404472664

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

ECMC Operator Number: 10814 Contact Name: Richard Saadeh
 Name of Operator: MDS ENERGY DEVELOPMENT LLC Phone: (817) 718-0175
 Address: 409 BUTLER RD SUITE A Fax: _____
 City: KITTANNING State: PA Zip: 16201 Email: richard.saadeh@mdsed.com

For "Intent" 24 hour notice required, Name: Petrie, Erica Tel: (303) 726-3822
ECMC contact: Email: erica.petrie@state.co.us

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number 05-123-05475-00
 Well Name: O CASTOR A Well Number: 1
 Location: QtrQtr: NWNW Section: 34 Township: 8N Range: 59W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: BUCKINGHAM Field Number: 7570

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.623016 Longitude: -103.971712
 GPS Data: GPS Quality Value: 1.1 Type of GPS Quality Value: PDOP Date of Measurement: 11/17/2025

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other Re-entry P&A offset to upcoming HZ development

Casing to be pulled: Yes No Estimated Depth: _____

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
D SAND	6706	6712	09/10/1969	SAND PLUG	6600

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	J55	32	0	370	200	370	0	VISU
1ST	7+7/8	5+1/2	J55	15.5	5000	6700	100	6700	6339	CALC
OPEN HOLE	7+7/8				6700	6722				

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 80 sks cmt from 5000 ft. to 4800 ft. Plug Type: STUB PLUG Plug Tagged:
Set 80 sks cmt from 2500 ft. to 2300 ft. Plug Type: OPEN HOLE Plug Tagged:
Set 80 sks cmt from 1575 ft. to 1375 ft. Plug Type: OPEN HOLE Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 148 sacks half in. half out surface casing from 420 ft. to 0 ft. Plug Tagged:
Set _____ sacks at surface
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____
Surface Plug Setting Date: _____ Cut and Cap Date: _____
*Wireline Contractor: _____ *Cementing Contractor: _____
Type of Cement and Additives Used: _____
Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

*Csg cut attempted; cut and pull depth/quantity unknown. Listed 5000' as possible cut depth
**Will tag and record top of production casing before pumping stub plug.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Taylor Heffner
Title: MDS Energy Contractor Date: _____ Email: theffner@carbon-shield.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with ECMC Rules and applicable orders and is hereby approved.

ECMC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY LIST

Expiration Date: _____

<u>COA Type</u>	<u>Description</u>
0 COA	

ATTACHMENT LIST

<u>Att Doc Num</u>	<u>Name</u>
404472692	SURFACE OWNER CONSENT
404472694	WELLBORE DIAGRAM
404472696	WELLBORE DIAGRAM
404472698	LOCATION PHOTO

Total Attach: 4 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)