

Document Number:
 404628543

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

ECMC Operator Number: 83130 Contact Name: Shawn Reed

Name of Operator: STRACHAN EXPLORATION INC Phone: (303) 5626530

Address: 992 S 4TH AVE SUITE 100-461 Fax: _____

City: BRIGHTON State: CO Zip: 80601 Email: shawn@strachanexploration.com

For "Intent" 24 hour notice required, Name: Serna, Abe Tel: (720) 661-7317

ECMC contact: Email: abe.serna@state.co.us

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number 05-011-06167-00

Well Name: HUMPHREY-WOLLERT Well Number: 2

Location: QtrQtr: NENE Section: 5 Township: 21S Range: 48W Meridian: 6

County: BENT Federal, Indian or State Lease Number: _____

Field Name: MCCLAVE Field Number: 53600

Only Complete the Following Background Information for Intent to Abandon

Latitude: 38.264675 Longitude: -102.818354

GPS Data: GPS Quality Value: 5.0 Type of GPS Quality Value: _____ Date of Measurement: 03/27/2010

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems

Other _____

Casing to be pulled: Yes No Estimated Depth: _____

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
MORROW	4661	4671		B PLUG CEMENT TOP	4610

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
1ST	12+1/4	8+5/8	j-55	24	0	371	235	371	0	VISU
S.C. 2.1	7+7/8	4+1/2	j-55	10.5	0	4839	295	4839	2990	CBL
S.C. 2.2	7+7/8	4+1/2	j-55	10.5	0	2990	580	2990	0	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 4610 with 4 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 25 sks cmt from 3100 ft. to 2800 ft. Plug Type: CASING Plug Tagged:
Set 65 sks cmt from 2050 ft. to 1200 ft. Plug Type: CASING Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 35 sacks half in. half out surface casing from 471 ft. to 0 ft. Plug Tagged:
Set _____ sacks at surface
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____
Surface Plug Setting Date: _____ Cut and Cap Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

Surface plug inside the 4 1/2" from 471 to surface, Annulus was covered on 2nd stg of the Production string
Please add the COA to get the correct GPS and we'll get it from location.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Shawn reed
Title: Petroleum Consultant Date: _____ Email: shawn@strachanexploration.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with ECMC Rules and applicable orders and is hereby approved.

ECMC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY LIST

Expiration Date: _____

COA Type	Description
0 COA	

ATTACHMENT LIST

Att Doc Num	Name
404632826	WELLBORE DIAGRAM
404632828	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

User Group	Comment	Comment Date
Permit	WBDs are for incorrect well. As-drilled GPS is inaccurate. Please correct prior to resubmission or COA to collect new coordinates will be placed upon resubmission. Returned to draft.	04/22/2026

Total: 1 comment(s)