



1120 Lincoln Street, Suite 801, Denver, Colorado 80203 (303) 894-2100 Fax (303) 894-2109

## WELL ABANDONMENT REPORT

Submit original plus one copy. This form is to be submitted as an intent whenever a plugging is planned on a borehole. The approved intent shall be valid for twelve months after the approval date after that period a new intent will be required. After the plugging is complete, this form and one copy shall again be submitted as a subsequent report of the work as actually completed.

**RECEIVED**  
MAY 17 2010  
COGCC

<b>COGCC Operator Number:</b> 51130 <b>Name of Operator:</b> Locin Oil Corporation <b>Address:</b> 25231 Grogan's Mill Road, Suite 500 <b>City:</b> The Woodlands <b>State:</b> TX <b>Zip:</b> 77380		<b>Contact Name &amp; Telephone:</b> Mark Clavenna <b>No:</b> 281-362-8600 (22) <b>Fax:</b> 281-419-6626	<b>24 hour notice required, contact:</b> _____ Tel: _____																					
<b>API Number:</b> 05-103-08658 <b>Well Name:</b> Fork Unit <b>Well Number:</b> 5-23-1-2 <b>Location (QtrQtr, Sec, Twp, Rng, Meridian):</b> SWNW, Sec 23, T1S, R102W <b>County:</b> Rio Blanco <b>Federal, Indian or State Lease Number:</b> C-02743 <b>Field Name:</b> Douglas Creek North <b>Field Number:</b> 17900		<b>Complete the Attachment Checklist</b> <table border="1"> <thead> <tr> <th></th> <th>Oper</th> <th>OGCC</th> </tr> </thead> <tbody> <tr> <td>Wellbore Diagram</td> <td>X</td> <td></td> </tr> <tr> <td>Cement Job Summary</td> <td></td> <td></td> </tr> <tr> <td>Wireline Job Summary</td> <td></td> <td></td> </tr> <tr> <td> </td> <td></td> <td></td> </tr> <tr> <td> </td> <td></td> <td></td> </tr> <tr> <td> </td> <td></td> <td></td> </tr> </tbody> </table>			Oper	OGCC	Wellbore Diagram	X		Cement Job Summary			Wireline Job Summary											
	Oper	OGCC																						
Wellbore Diagram	X																							
Cement Job Summary																								
Wireline Job Summary																								

☒ **Notice of Intent to Abandon**

☐ **Subsequent Report of Abandonment**

### Only Complete the Following Background Information for Intent to Abandon

**Latitude:** \_\_\_\_\_ **Longitude:** \_\_\_\_\_  
**GPS Data:** \_\_\_\_\_  
**Date of Measurement:** \_\_\_\_\_ **PDOP Reading:** \_\_\_\_\_ **Instrument Operator's Name:** \_\_\_\_\_  
**Reason for Abandonment:** ☐ Dry ☐ Production Sub-economic ☐ Mechanical Problems ☐ Other  
**Casing to be Pulled:** ☐ Yes ☒ No **Top of Casing Cement:** Unknown  
**Fish in Hole:** ☐ Yes ☒ No **If yes, explain details below**  
**Wellbore has Uncemented Casing Leaks:** ☐ Yes ☒ No **If yes, explain details below**  
**Details:** \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

### Current and Previously Abandoned Zones

Formation	Perforations - Top	Perforations - Bottom	Date Abandoned	Method of Isolation (None, Squeezed, BP, Cement, etc.)	Plug Depth
Mancus B	2358	2450			

### Casing History

String	Size of Hole	Size of Casing	Weight per ft	Setting Depth	Sacks Cement	Cement Bottom	Cement Top
Surface	12.25	8.625	24	180	180	180	0
Prod	7.875	5.5	15.5	2633	350	2633	
				7636			

### Plugging Procedure for Intent and Subsequent Report

**CIBP #1: Depth** 2310 **with** 2 **sacks cmt on top.** **CIBP #2: Depth** \_\_\_\_\_ **with** \_\_\_\_\_ **sacks cmt on top**  
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in ☐ Casing ☐ Open Hole ☐ Annulus  
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in ☐ Casing ☐ Open Hole ☐ Annulus  
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in ☐ Casing ☐ Open Hole ☐ Annulus  
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in ☐ Casing ☐ Open Hole ☐ Annulus  
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in ☐ Casing ☐ Open Hole ☐ Annulus  
 Perforate and squeeze at 1000 ft. with 50 sacks Leave at least 100 ft. in casing  
 Perforate and squeeze at 230 ft. with 75 sacks Leave at least 100 ft. in casing  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks Leave at least 100 ft. in casing  
 Set \_\_\_\_\_ sacks half in, half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft.  
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate  
 Set \_\_\_\_\_ sacks in rat hole **Dry-Hole Marker:** ☒ Yes ☐ No  
 Set \_\_\_\_\_ sacks in mouse hole

NOTE: Two (2) sacks cement required on all CIBPs.

### Additional Plugging Information for Subsequent Report Only

**Casing Recovered:** \_\_\_\_\_ ft. of \_\_\_\_\_ in. casing **Plugging date:** \_\_\_\_\_  
**\*Wireline Contractor:** \_\_\_\_\_ **\*Cementing Contractor:** \_\_\_\_\_  
**Type of Cement and Additives Used:** \_\_\_\_\_  
**\*Attach job summaries.**

I hereby certify that the statements made in this form are, to the best of my knowledge, true, correct, and complete.

**Print Name:** Mark Clavenna **Email:** mclavenna@nclnr.com  
**Signed:** Mark Clavenna **Title:** Manager **Date:** 05/11/10

**OGCC Approved:** [Signature] **Title:** EIT II **Date:** 5/26/2010

CONDITIONS OF APPROVAL, IF ANY:

GPS coord. required for Form 6,  
Subsequent

Fax → OPR 5/26/2010