

SUNDRY NOTICE

Submit original plus one copy. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full on Technical Information Page (Page 2 of this form.)

1. OGCC Operator Number: 96850
2. Name of Operator: WPX Energy LLC
3. Address: 1001 17th Street, Suite 1200
4. Contact Name: Howard Harris
5. API Number: 05-045-15906-00
6. Well/Facility Name: Federal
7. Well/Facility Number: RWF 534-7
8. Location (Qtr/Qtr, Sec, Twp, Rng, Meridian): NENW Sec. 18-T6S-94W
9. County: Garfield
10. Field Name: RULISON

General Notice

CHANGE OF LOCATION: Attach New Survey Plat
CHANGE SPACING UNIT
CHANGE OF OPERATOR (prior to drilling):
CHANGE WELL NAME
ABANDONED LOCATION:
NOTICE OF CONTINUED SHUT IN STATUS
SPUD DATE:
REQUEST FOR CONFIDENTIAL STATUS
SUBSEQUENT REPORT OF STAGE, SQUEEZE OR REMEDIAL CEMENT WORK
RECLAMATION:

Technical Engineering/Environmental Notice

X Notice of Intent
Approximate Start Date: Dependent on Rig Availability
Request to Vent or Flare
Request to Repair Well
Request for Rule 502 variance
Other: Squeeze high water interval


I hereby certify that the statements made in this form are, to the best of my knowledge, true, correct and complete.

Signed: Howard Harris Date: 9/24/12 Email: Howard.Harris@Williams.com
Print Name: Howard Harris Title: Sr. Regulatory Specialist

COGCC Approved: [Signature] Title: NWAE Date: 11/5/12
CONDITIONS OF APPROVAL, IF ANY:

FORM
4
Rev 12/05

TECHNICAL INFORMATION PAGE



1. OGCC Operator Number: 96850 API Number: 05-045-15906-00
 2. Name of Operator: WPX Energy LLC OGCC Facility ID # _____
 3. Well/Facility Name: Federal Well/Facility Number: RWF 534-7
 4. Location (QtrQtr, Sec, Twp, Rng, Meridian): NENW Sec. 18-T6S-94W

This form is to be completed whenever a Sundry Notice is submitted requiring detailed report of work to be performed or completed. This form shall be transmitted within 30 days of work completed as a "subsequent" report and must accompany Form 4, page 1.

5. **DESCRIBE PROPOSED OR COMPLETED OPERATIONS**

Williams wishes to identify and isolate high water interval in subject well per following procedure.



Exploration and Production Water Squeeze Procedure

Wellname: **RWF 534-7**
 Location: **NENW 18-6S-94W**
 Field: **Rulison**
 API: **05-045-15906**

Prepared By: Michael Andrews
 cell phone: (970) 433-8704

Date: 9/20/2012

Surface Casing: 9-5/8" 32.3# set @ 3,465-ft
 Production Casing: 4-1/2" 11.6# set @ 9,754-ft
 PBTD: 9,716-ft
 TOC: 4,600-ft
 Tubing: 2-3/8" tbg @ 8,946-ft
 MV Completions: MV/Cameo (7,304 - 9,512 ft)
 Correlate Log: HAL CBL - 11/27/2008

Purpose: Identify and isolate high water producing zone

Proposed Procedure:

- 1 POOH w/ 2-3/8" tbg
- 2 RIH set RBP and packer and identify high water producing zone
- 3 POOH w/ packer and tubing
- 4 RIH and remediate high water producing zone with Class G cement
- 5 POOH w/ down hole equipment
- 6 Drill out cement and test to 1500 psi
- 7 RIH with tubing and return to production
- 8 Submit subsequent report