

**WORKOVER PROCEDURE**

**WELL NAME:** OAKLAND CATTLE COMPANY 32-27 2 **DATE:** 7/17/2013

**LOCATION:** \_\_\_\_\_

Qtr/Qtr: SWNE Section: 27 Township: 5S Range: 61W  
**COUNTY:** ARAPAHOE **STATE:** CO **API #:** 05-005-06809

**ENGINEER:** LEAH PERKINS 7 Day Notice Sent: \_\_\_\_\_  
(Please notify Engineer of any major Do not start operations until: \_\_\_\_\_  
changes prior to work) Notice Expires: \_\_\_\_\_

**OBJECTIVE:** P&A

**WELL DATA:** Surface Csg: 8 5/8" 24# @ 227' KB Elevation: 5451  
Surface Cmt: 200 sx GL Elevation: 5440  
Long St Csg: 5 1/2" 15.50# @ 6935' TD: 6935  
Long St Cmt: 285 sx PBTD: \_\_\_\_\_  
Long St Date: \_\_\_\_\_

Plug Back (Sand or CIBP): \_\_\_\_\_  
Perforation Interval (1): J Sand Perforations 6781' - 6793'  
Perforation Interval (2): \_\_\_\_\_  
Perforation Interval (3): \_\_\_\_\_  
Tubing: \_\_\_\_\_ Rods: \_\_\_\_\_  
Pump: \_\_\_\_\_  
Misc.: \_\_\_\_\_

**PRODUCTION STATUS:** \_\_\_\_\_  
**COMMENTS:** \*No data in wellfile on tubing or PBTD

**PROCEDURE:**

- 1) MIRU Workover rig, pump & tank.
- 2) POOH w/ tbg and lay down. (No data in wellfile on tubing size)
- 3) RU WL. RIH w/CIBP. Set CIBP @ 6681', dump bail 2 sx of cement on top.
- 4) Run CBL to determine TOC.
- 5) Unland casing. Cut casing off +/- 5000'. POOH with casing laying down on trailer. (Compare depth with CBL)
- 6) RIH w/ workstring to pump (100) sx stub plug where csg was pulled. If maintain circulation, do not need to tag plug.
- 7) Pump 50 sx Courtesy Plug @ 2500'. POOH w/workstring to 330'. Pump approx 150 sx shoe plug. Cement to surface.
- 8) RIH. Tag shoe plug. Add cement if needed.
- 9) Cut surface casing off 6'-8' below ground.
- 10) Clean up location. Reclaim location. RDMO.