

Lucas School 33-9

County: Weld
api# 0512319315
Field: Wattenberg

Well Notes:

- Step 1.) Contact landowner 24 hours prior to commencing work on this well.
- 2.) MIRU pulling unit
- 3.) ND Wellhead, NU BOP
- 4.) TOOH w/ 1-7/8" Tubing
- 5.) TIH w/ 1-7/8" tbg w/ bit & scraper
- 6.) MU & TIH w/ 3-1/2" retrievable bridge plug (RBP)
- 7.) Set RBP @ 7,206'; 50' above Codell Perforations
- 8.) TOOH w/ 1-7/8" tbg
- 9.) RU rig pump & pressure test csg to 500psi for 15 minutes;
- 10.) Chart record pressure test
- 11.) TIH down 3-1/2" x 8-5/8" annulus w/ 1,000' 1-1/2" IJ tbg
- 12.) MI cementers and break circ w/ water; then pump 20 bbl spacer to clean hole
- 13.) Pump 250 sxs class G down IJ tbg; stop if it circulates earlier
- 14.) Pump water down tbg to disp cmt
- 15.) TOOH w/ 1-1/2" tbg, washing up
- 16.) MI wireline and run GR/CCL/CBL
- 17.) ND BOP, NU Tree & Flowline
- 18.) Turn in final MIT sundry to State w/ CBL