

## WORKOVER PROCEDURE

**WELL NAME:** ANDERSON E24-12 **DATE:** 2/19/2014

**LOCATION:** Qtr/Qtr: NWSW Section: 24 Township: 6N Range: 65W

**COUNTY:** WELD STATE: CO API #: 05-123-16841

**ENGINEER:** SETH GORDON 7 Day Notice Sent: \_\_\_\_\_  
(Please notify Engineer of any major Do not start operations until: \_\_\_\_\_  
changes prior to work) Notice Expires: \_\_\_\_\_

**OBJECTIVE:** P&A

**WELL DATA:** Surface Csg: 8 5/8" @ 349' KB Elevation: 4708'  
Surface Cmt: 300 sx GL Elevation: 4696'  
Long St Csg: 2 7/8" 6.5# @ 7125' TD: 7128'  
Long St Cmt: 330 sx prod/270 sx stage PBTD: 7121'  
Long St Date: 3/22/1993

Plug Back (Sand or CIBP): \_\_\_\_\_  
Perforation Interval (1): Codell Perforations 6967' - 6983'  
Perforation Interval (2): \_\_\_\_\_  
Perforation Interval (3): \_\_\_\_\_  
Tubing: 1 1/2" tubing @ 6923' Rods: \_\_\_\_\_  
Pump: \_\_\_\_\_  
Misc.: Casing patch in 2003, 314 sx via annular fill (1728' - 3381', calculated)

**PRODUCTION STATUS:** \_\_\_\_\_  
**COMMENTS:** \_\_\_\_\_

### PROCEDURE:

- 1) MIRU Workover rig, pump & tank.
- 2) POOH w/ 1 1/2" tbg and lay down.
- 3) RU WL. RIH w/CIBP. Set CIBP @ 6917'.
- 4) Load hole, run CBL from CIBP to surface to verify uphole cement.  
(Annular fill top estimated at 1728')
- 5) RIH w/ WL, dump bail 2 sx cement on CIBP.
- 6) RIH w/ workstring to 3600'. Pump 60 sx balance plug. POOH.
- 7) Unland casing. Cut casing off 600'. POOH with casing laying down on trailer.
- 8) RIH w/ workstring to pump 275 sx stub/shoe plug where csg was pulled. Circulate to surface
- 9) WOC 4 hours. RIH. Tag shoe plug. Add cement if needed.
- 10) Cut surface casing off 6'-8' below ground.
- 11) Clean up location. Reclaim location. RDMO.