



FRU 297-32A Wells Conductor Plugging Procedure

Prepared by Bola Adeyeye. Office: (303) 3973606 Cell: (720) 5391660

The procedure is for the plugging and abandonment for the following wells on FRU 297-32A pad that have only the conductors:

FRU 297-32A6, FRU297-32A7, FRU 297-32A8, FRU 297-32A9, FRU 297-32A10

1. Prepare the location for plugging work.
2. Move in cement truck, might need a crane to pull and support string/tubing to spot cement
3. Mix 160 sacks of Class G neat cement in 19bbl fresh water to make 32 bbl of 15.8 ppg slurry.
4. Insure cement is mixed adequately; depth of conductor is approximately 150 ft and 15.01" inner diameter (Conductor size: 16" 84 lb/ft J55).
 - ~ 32 bbl of cement will be required for 150ft conductor (0.2186 bbl/ft)
5. Run pipe into the conductor, tag bottom and pick up ~5 ft.
6. Resume spotting/pumping of the cement, trip pipe out of the conductor as the cement level rise to insure pipe is above the cement.
7. Continue uphole until 4 ft from the ground level. Pull and lay down the remaining spotting pipe.
8. Cut the conductor 4 feet from the surface. Spot additional cement inside the hole. Mark and redress location, move onto next well.