

**WORKOVER PROCEDURE**

**WELL NAME:** BURKE 24-03 **DATE:** 3/26/2014

**LOCATION:** Qtr/Qtr: NE/SE Section: 24 Township: 4N Range: 65W

**COUNTY:** WELD STATE: CO API #: 05-123-14522

**ENGINEER:** JONATHAN POMERANTZ 7 Day Notice Sent: \_\_\_\_\_  
(Please notify Engineer of any major Do not start operations until: \_\_\_\_\_  
changes prior to work) Notice Expires: \_\_\_\_\_

**OBJECTIVE:** P&A

**WELL DATA:** Surface Csg: 8 5/8" 24# @ 439' KB Elevation: 4839'  
Surface Cmt: 280 sx GL Elevation: 4830'  
Long St Csg: 4 1/2" 15.1# @ 7198' TD: 7225'  
Long St Cmt: 1020 sx PBTD: 7174'  
Long St Date: 1/13/1990

Plug Back (Sand or CIBP): \_\_\_\_\_  
Perforation Interval (1): Niobrara Perforations 6839' - 7015'  
Perforation Interval (2): Codell Perforations 7124' - 7138'  
Perforation Interval (3): \_\_\_\_\_  
Tubing: 2 3/8" 4.7# J-55 tbg @ 7109' Rods: \_\_\_\_\_  
Pump: \_\_\_\_\_  
Misc.: \_\_\_\_\_

**PRODUCTION STATUS:** \_\_\_\_\_  
**COMMENTS:** \_\_\_\_\_

- PROCEDURE:**
- 1) MIRU Workover rig, pump & tank.
  - 2) POOH w/ 2 3/8" tbg and lay down.
  - 3) RU WL. RIH w/CIBP. Set CIBP @ 6789', dump bail 2 sx of cement on top.
  - 4) RIH w/ workstring to 4900'. Pump 125 sx balance plug. SI, WOC. RIH. Tag balance plug @ approx 3250'.
  - 5) Pump 50 sx Courtesy Plug @ 2500'. POOH w/workstring to 700'. Pump approx 55 sx shoe plug. Cement to surface.
  - 6) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
  - 7) Cut surface casing off 6'-8' below ground.
  - 8) Clean up location. Reclaim location. RDMO.