

Plugging Program for IGE 401

- 1) MOL RU. TOOH with 2-3/8" tubing.
- 2) PU and TIH with 5-1/2" retainer to 7709'. Squeeze below retainer with 10 sx cmt. Sting out and spot 6 sx on top of retainer.
- 3) Pull up to 5294'. Spot balanced cement plug with 17 sx to cover top of Mesa Verde.
- 4) Pull up to 3463'. Spot balanced cement plug with 105 sx to cover tops of Fruitland, Pictured Cliffs, and intermediate casing shoe.
- 5) Pull up to 591'. Mix and pump 67 sx, or sufficient volume, to bring cement to surface inside 5-1/2" long string.
- 6) Cut off well head 4 feet below surface and remediate location in accordance with regulatory agencies' conditions of approval.