

FORM
6Rev
12/05

State of Colorado Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Replug By Other Operator

Document Number:

400629210

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175

Contact Name: Christine Brookshire

Name of Operator: PDC ENERGY INC

Phone: (303) 860-5800

Address: 1775 SHERMAN STREET - STE 3000

Fax: (303) 860-5838

City: DENVER State: CO Zip: 80203

Email: christine.brookshire@pdce.com

For "Intent" 24 hour notice required,

Name: _____

Tel: _____

COGCC contact:

Email: _____

API Number 05-123-05301-00

Well Name: Don Anderson

Well Number: 1

Location: QtrQtr: NENW Section: 34 Township: 7N Range: 66W Meridian: 6

County: WELD

Federal, Indian or State Lease Number: _____

Field Name: WILDCAT

Field Number: 99999

☐ Notice of Intent to Abandon☒ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.536793

Longitude: -104.766703

GPS Data:

Date of Measurement: 03/21/2001

PDOP Reading: 6.0

GPS Instrument Operator's Name: COGCC Website

Reason for Abandonment:

☐ Dry☐ Production for Sub-economic☐ Mechanical Problems☐ Other _____Casing to be pulled: ☐ Yes☐ No

Estimated Depth: _____

Fish in Hole: ☐ Yes☐ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☐ No

If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation

Perf. Top

Perf. Btm

Abandoned Date

Method of Isolation

Plug Depth

--	--	--	--	--	--

Total: 0 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	10+3/4	24	396	200	396	0	VISU

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 150 sks cmt from 7740 ft. to 7478 ft. Plug Type: OPEN HOLE Plug Tagged: ☐
Set 698 sks cmt from 2833 ft. to 5006 ft. Plug Type: OPEN HOLE Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 200 sacks half in. half out surface casing from 526 ft. to 2 ft. Plug Tagged: ☒

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing

Plugging Date: 01/20/2014

*Wireline Contractor: _____

*Cementing Contractor: Baker Hughes

Type of Cement and Additives Used: Class G Cement + bwoc Bentonite

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No

*ATTACH JOB SUMMARY

Technical Detail/Comments:

Lyons
PBSD: 9253'

operator.

Procedure:

- 1)MIRU Excavation crew
- 2)Locate and dig up old wellhead
- 3)Cut old casing and weld new casing stub to bring to surface, fill in hole
- 4)MIRU workover rig
- 5)RIH w/ bit, tag and drill through surface plug
- 6)RIH to clean out to J-Sand (7848')
- 7)Set 150 sack plug above J-Sand (7478' to 7740'), POOH
- 8)TIH to tag J-Sand Plug
- 9)TOH to set 698 sack 13.55ppg plug from 2833' to 5006'
- 10)TOH to set 200 sack 15.8ppg plug from 2' to 526' , POOH
- 11)TIH to tag cement at 2' , POOH
- 12)Cut casing and weld on cap

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____

Print Name: Christine Brookshire

Title: Regulatory Tech

Date: _____

Email: christine.brookshire@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved. _____

COGCC Approved:

Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400633091	WELLBORE DIAGRAM
400633673	CEMENT JOB SUMMARY
400648892	CEMENT BOND LOG

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)