

**WORKOVER PROCEDURE**

**WELL NAME:** MONFORT 5-9 **DATE:** 8/4/2014

**LOCATION:** Qtr/Qtr: SWNW Section: 9 Township: 4N Range: 66W  
**COUNTY:** WELD STATE: CO API #: 05-123-22135

**ENGINEER:** Jacob Eicher 7 Day Notice Sent: \_\_\_\_\_  
(Please notify Engineer of any major Do not start operations until: \_\_\_\_\_  
changes prior to work) Notice Expires: \_\_\_\_\_

**OBJECTIVE:** Annular Fill

**WELL DATA:** Surface Csg: 8 5/8" 24# J-55 @ 592' KB Elevation: 4707'  
Surface Cmt: 592' GL Elevation: 4697'  
Long St Csg: 4 1/2" 11.6# I-80 @ 7834' TD: 7845'  
Long St Cmt: 3100' - 7834' PBDT: 7807'  
Long St Date: 5/15/2004

Plug Back (Sand or CIBP): TAG  
Perforation Interval (1): NIOBRARA: 6894' - 7089'  
Perforation Interval (2): CODELL: 7212' - 7228'  
Perforation Interval (3): J SAND: 7684' - 7735'

Tubing: 2 3/8" 4.7# J-55 @ 7176' Rods: \_\_\_\_\_  
Pump: \_\_\_\_\_  
Misc.: \_\_\_\_\_

**PRODUCTION STATUS:** 10 BOEPD  
**COMMENTS:** Base of Fox Hills @ 329'

**PROCEDURE:**

- 1) MIRU Workover rig, pump & tank.
- 2) Control well with kill fluid
- 3) POOH w/ 2 3/8" tubing
- 4) RIH w/ Bit & Scraper. Tag fill if any. Clean out to PBDT (tally in). TOOH
- 5) RIH w/RBP. Set RBP @ +/- 6850', spot 2 sx of sand on top of RBP. Test RBP 2,000psi. TOOH
- 6) Bleed off bradenhead, unland casing
- 7) Trip in 1 1/4" tubing down annular w/ mule shoe to +/- 1792', condition hole.
- 8) RU cement crew, pump 360 sxs 15.8 ppg "G" neat cement to cover the interval 792' - 1792'
- 9) POOH with 1 1/4" tubing, land casing.
- 10) SI well overnight, run CBL recording new cement depths
- 11) Clean out hole and consult work schedule for direction regarding leaving plug, setting packer, or changing the wellhead