

State of Colorado
Oil and Gas Conservation Commission1120 Lincoln Street, Suite 801, Denver, Colorado 80203
Phone: (303) 894-2100 Fax: (303) 894-2109

DE	ET	OE	ES
Document Number: 400694959			
Date Received:			

SUNDRY NOTICE

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number:	47120	Contact Name	Cheryl Light
Name of Operator:	KERR MCGEE OIL & GAS ONSHORE LP		Phone: (720) 929-6461
Address:	P O BOX 173779		Fax: (720) 929-7461
City:	DENVER	State:	CO Zip: 80217-3779 Email: cheryl.light@anadarko.com

Complete the Attachment
Checklist

OP OGCC

API Number :	05-	123	22100	00	OGCC Facility ID Number:	271683
Well/Facility Name:	CAMP H			Well/Facility Number:	30-19	
Location	QtrQtr:	SWNW	Section:	30	Township:	3N Range: 65W Meridian: 6
County:	WELD		Field Name:	WATTENBERG		
Federal, Indian or State Lease Number:						

Survey Plat		
Directional Survey		
Srvc Eqpmt Diagram		
Technical Info Page		
Other		

CHANGE OF LOCATION OR AS BUILT GPS REPORT

☐ Change of Location * ☐ As-Built GPS Location Report ☐ As-Built GPS Location Report with Survey

* Well location change requires new plat. A substantive surface location change may require new Form 2A.

SURFACE LOCATION GPS DATA Data must be provided for Change of Surface Location and As Built Reports.

Latitude _____ PDOP Reading _____ Date of Measurement _____
Longitude _____ GPS Instrument Operator's Name _____

LOCATION CHANGE (all measurements in Feet)

Well will be: _____ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:Change of **Surface** Footage **To** Exterior Section Lines:Current **Surface** Location **From** QtrQtr **SWNW** Sec **30**New **Surface** Location **To** QtrQtr _____ Sec _____Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:Current **Top of Productive Zone** Location **From** Sec _____New **Top of Productive Zone** Location **To** Sec _____Change of **Bottomhole** Footage **From** Exterior Section Lines:Change of **Bottomhole** Footage **To** Exterior Section Lines:Current **Bottomhole** Location Sec _____ Twp _____New **Bottomhole** Location Sec _____ Twp _____

Is location in High Density Area? _____

Distance, in feet, to nearest building _____, public road: _____, above ground utility: _____, railroad: _____,
property line: _____, lease line: _____, well in same formation: _____

Ground Elevation _____ feet Surface owner consultation date _____

FNL/FSL		FEL/FWL	
1423	FNL	1271	FWL
Twp 3N	Range 65W	Meridian 6	
Twp	Range	Meridian	
			**
Twp	Range		
Twp	Range		
			**
			** attach deviated drilling plan

CHANGE OR ADD OBJECTIVE FORMATION AND/OR SPACING UNIT

<u>Objective Formation</u>	<u>Formation Code</u>	<u>Spacing Order Number</u>	<u>Unit Acreage</u>	<u>Unit Configuration</u>

OTHER CHANGES

☐ **REMOVE FROM SURFACE BOND** Signed surface use agreement is a required attachment

☐ **CHANGE OF WELL, FACILITY OR OIL & GAS LOCATION NAME OR NUMBER**

From: Name CAMP H Number 30-19 Effective Date: _____

To: Name _____ Number _____

☐ **ABANDON PERMIT: Permit can only be abandoned if the permitted operation has NOT been conducted. Field inspection will be conducted to verify site status.**

☐ WELL: Abandon Application for Permit-to-Drill (Form2) – Well API Number _____ has not been drilled.

☐ PIT: Abandon Earthen Pit Permit (Form 15) – COGCC Pit Facility ID Number _____ has not been constructed (Permitted and constructed pit requires closure per Rule 905)

☐ **CENTRALIZED E&P WASTE MANAGEMENT FACILITY:** Abandon Centralized E&P Waste Management Facility Permit (Form 28) – Facility ID Number _____ has not been constructed (Constructed facility requires closure per Rule 908)

OIL & GAS LOCATION ID Number: _____

☐ Abandon Oil & Gas Location Assessment (Form 2A) – Location has not been constructed and site will not be used in the future.

☐ Keep Oil & Gas Location Assessment (Form 2A) active until expiration date. This site will be used in the future.

Surface disturbance from Oil and Gas Operations must be reclaimed per Rule 1003 and Rule 1004.

☐ **REQUEST FOR CONFIDENTIAL STATUS**

☐ **DIGITAL WELL LOG UPLOAD**

☐ **DOCUMENTS SUBMITTED** Purpose of Submission: _____

RECLAMATION**INTERIM RECLAMATION**

☐ Interim Reclamation will commence approximately _____

Per Rule 1003.e.(3) operator shall submit Sundry Notice reporting interim reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Interim reclamation complete, site ready for inspection.

Per Rule 1003.e(3) describe interim reclamation procedure in Comments below or provide as an attachment and attach required location photographs.

Field inspection will be conducted to document Rule 1003.e. compliance

FINAL RECLAMATION

☐ Final Reclamation will commence approximately _____

Per Rule 1004.c.(4) operator shall submit Sundry Notice reporting final reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Final reclamation complete, site ready for inspection. Per Rule 1004.c(4) describe final reclamation procedure in Comments below or provide as an attachment.

Field inspection will be conducted to document Rule 1004.c. compliance

Comments:

ENGINEERING AND ENVIRONMENTAL WORK

☐ NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned _____ Has Production Equipment been removed from site? _____

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT _____

☐ SPUD DATE: _____

TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK

Details of work must be described in full in the COMMENTS below or provided as an attachment.

☒ NOTICE OF INTENT Approximate Start Date 10/08/2014

☐ REPORT OF WORK DONE Date Work Completed _____

- | | | |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare | <input type="checkbox"/> E&P Waste Mangement Plan |
| <input type="checkbox"/> Change Drilling Plan | <input checked="" type="checkbox"/> Repair Well | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. | |
| <input type="checkbox"/> Other _____ | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases | |

COMMENTS:

Camp H 30-19: Remedial Cement, Annular Fill
1 Well has Gyro 2014
2 Call IOC (970.506.5980) before rig up to isolate production equipment. Catch and remove plunger. Enter plunger into PLUNGER DATABASE. Call 24 hours prior to the rig moving onto location so that any automation equipment can be removed prior to the rig showing up. Install fence if needed. If surface casing is not accessible at ground level, re-pipe so valve is at ground level.
3 Check for surface casing pressure, bleed off as necessary. If pressure does not bleed off report findings to Evans engineering office to determine if a change to the procedure is needed.
4 MIRU Cable slickline service company. RIH to retrieve production equipment. RIH and tag for fill, last cleanout to unknown - PBMD 7530'. Note tagged depth in OpenWells.
5 MIRU Workover (WO) Rig. Control well with biocide treated water. Nipple Down (ND) Wellhead (WH) and Nipple Up (NU) Blow Out Preventer Equipment (BOP). Function test and document BOP. Unseat landing joint and lay down (LO).
6 Spot 10 jnts 2-3/8" tbg for cleanout and replacement. Tie into 2-3/8" tbg string.
7 Cleanout to 7,530'.
8 MIRU EMI services. EMI 2-3/8" TBG on TOO H and tally while standing back. Lay down joints with wall loss or penetrations > 35%. Replace bad joints as necessary. Note joint number and depth of bad tubing and create Production Equipment Failure Report in OpenWells. ROMO EMI services.
9 PU TIH with 2-3/8" TBG and RBP rated to 10,000 psi (4-1/2", 11.6#, M-80) arid set at +/- 7,055' (reference NUEX Wireline CBL dated 7 /13/2004 - collars are at 7,041' and 7,084').
10 Circulate out any gas and load hole with casing valves open. Pressure test through BOP to 1000 psi for 15 minutes. If test fails contact Evans Engineering. Dump 2 sacks of sand onto RBP.
11 Be sure casing valves and nipples are rated to 5,000 psi, replace as necessary. PUH 1 jnt. Tie in 8' Sub with landing donut on the tubing string and land with the sub accessible above the BOP. Engage BOP pipe rams. Tighten pack off bolts.
12 MIRU hydrotester. Pressure test RBP to 5,000 psi using water w/ biocide for 15 min. If pressure test fails, contact Evans office for possible change in procedure.
13 Unland, TOO H and SB with 2-3/8" tbg. LO landing sub and landing donut.
14 ND BOP. Unland 4-1/2" production casing and NU double entry flange. 2004 vintage casing, don't pull with more than 130,000lbs
15 PU 164 jnts of 1-1/4"/2.33#/IJ tbg. Run in annulus to 5080' while circulating. Contact engineering if unable to make depth.
16 Circulate with the fluid already in annulus until returns are clean or at least 650 BBL.
17 MIRU Baker cementing services (we are trying a group of experimental cement jobs with 14.2# blend).
18 Mix & pump as follows: 20 bbls SAP mud flush (mud cake removal chemical solution), 10 bbl fresh water spacer, 200 sks POZ G cement & Y<i#sk Cello Flake, 0.4% Sodium Metasilicate, 0.4% FL-52, 0.1% CD-32, and 2% Bentonite mixed at 14.2 ppg and yield of 1.26 cuft/sk (CaCl2 amounts as determined by cementing service company for a 3 hour pumping time at 120°F) for a total of 44.9 bbl of cement. Design is for coverage from 5080' to 4339' in 8.5" Borehole (has caliper log) with a 20% excess. See Calculation if necessary.
19 POOH with 1-1/4" to +/- 4000' and circulate until clean. Finish POOH and SB 1-1/4" tbg.
20 Re-land 4-1/2 production casing.
21 Shut in and WOC 24 hours minimum.
22 MIRU Wireline Services. PU and RIH w/ CCL-CBL-VDL tools and log from 5,100' to 4,000'. NOTE: IF TOC is below 4400'

CASING AND CEMENTING CHANGES

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

H2S REPORTING

Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.

Gas Analysis Report must be attached.

H2S Concentration: _____ in ppm (parts per million)

Date of Measurement or Sample Collection _____

Description of Sample Point:

Absolute Open Flow Potential _____ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: _____

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: _____

COMMENTS:

Best Management Practices**No BMP/COA Type****Description**

--	--

Operator Comments:

OR POOR BOND, CONTACT EVANS FOR NEW PROCEDURE. Clear with Evans engineering and email logs to Jacob.Barker@Anadarko.com before proceeding. Email copies of logs, summaries and invoices to rscDJVendors@Anadarko.com within 24hrs.
23 POOH, ROMO wireline service company.
24 PU and TIH with RBP retrieving head and 2-3/8" tbg (4.7#/J-55/8rd EUE). Latch onto RBP and release. TOOH with tbg and RBP. SB tbg and laydown RBP.
25 PU and TIH with 2-3/8" NC, 2-3/8" XN profile nipple and 2-3/8" tbg. Land so EOT is at +/- 7380' (about 1 jnt above CD perfs at 7,408' - 7,418').
26 RU rig lubricator. Broach TBG to XN nipple. RD Lubricator.
27 PU 5,000 psi Flanged 7-1/16" x 2-1/16" EUE tubing head adapter, 2-16" EUE flanged 5,000 psi master valve with 2-3/8" EUE companion flange on top and 2-1/16" EUE flanged Lubricator.
28 ND BOP, NU WH with all flanged components.
29 Install 2-3/8" pup joint above master valve. Pressure test WH from below TBG head through master valve w/hydrotester to 5,000 psi.
30 ROMO WO rig. Return well to production team.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Cheryl Light
Title: Sr. Regulatory Analyst Email: DJRegulatory@anadarko.com Date: _____

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY:**General Comments**

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
<input type="text"/>	<input type="text"/>	<input type="text"/>

Total: 0 comment(s)

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
<input type="text"/>	<input type="text"/>

Total Attach: 0 Files