

**State of Colorado**  
**Oil and Gas Conservation Commission**

1120 Lincoln Street, Suite 801, Denver, Colorado 80203  
Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: <b>400714067</b>			
Date Received:			

**SUNDRY NOTICE**

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number: 100322 Contact Name KATHLEEN MILLS  
 Name of Operator: NOBLE ENERGY INC Phone: (720) 587-2226  
 Address: 1625 BROADWAY STE 2200 Fax: (303) 228-4286  
 City: DENVER State: CO Zip: 80202 Email: kmills@nobleenergyinc.com

Complete the Attachment  
Checklist

OP OGCC

API Number : 05- 123 16255 00 OGCC Facility ID Number: 248457  
 Well/Facility Name: KARCH BLUE Well/Facility Number: DD 18-3J  
 Location QtrQtr: NESW Section: 18 Township: 3N Range: 63W Meridian: 6  
 County: WELD Field Name: WATTENBERG  
 Federal, Indian or State Lease Number: \_\_\_\_\_

Survey Plat		
Directional Survey		
Srfc Eqpmt Diagram		
Technical Info Page		
Other		

**CHANGE OF LOCATION OR AS BUILT GPS REPORT**

- Change of Location \*       As-Built GPS Location Report       As-Built GPS Location Report with Survey

\* Well location change requires new plat. A substantive surface location change may require new Form 2A.

**SURFACE LOCATION GPS DATA** Data must be provided for Change of Surface Location and As Built Reports.

Latitude \_\_\_\_\_ PDOP Reading \_\_\_\_\_ Date of Measurement \_\_\_\_\_  
 Longitude \_\_\_\_\_ GPS Instrument Operator's Name \_\_\_\_\_

**LOCATION CHANGE (all measurements in Feet)**

Well will be: \_\_\_\_\_ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:

FNL/FSL		FEL/FWL	
<input type="text" value="1643"/>	<input type="text" value="FSL"/>	<input type="text" value="1650"/>	<input type="text" value="FWL"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Change of **Surface** Footage **To** Exterior Section Lines:

Current **Surface** Location **From** QtrQtr  Sec  Twp  Range  Meridian   
 New **Surface** Location **To** QtrQtr  Sec  Twp  Range  Meridian

Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:

<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:

Current **Top of Productive Zone** Location **From** Sec

Twp  Range

New **Top of Productive Zone** Location **To** Sec

Twp  Range

Change of **Bottomhole** Footage **From** Exterior Section Lines:

<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Change of **Bottomhole** Footage **To** Exterior Section Lines:

Current **Bottomhole** Location Sec  Twp

Range  \*\* attach deviated drilling plan

New **Bottomhole** Location Sec  Twp

Range

Is location in High Density Area? \_\_\_\_\_

Distance, in feet, to nearest building \_\_\_\_\_, public road: \_\_\_\_\_, above ground utility: \_\_\_\_\_, railroad: \_\_\_\_\_,

property line: \_\_\_\_\_, lease line: \_\_\_\_\_, well in same formation: \_\_\_\_\_

Ground Elevation \_\_\_\_\_ feet Surface owner consultation date \_\_\_\_\_



Comments:

**ENGINEERING AND ENVIRONMENTAL WORK**

NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned \_\_\_\_\_ Has Production Equipment been removed from site? \_\_\_\_\_

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT \_\_\_\_\_

SPUD DATE: \_\_\_\_\_

**TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK**

Details of work must be described in full in the COMMENTS below or provided as an attachment.

NOTICE OF INTENT Approximate Start Date 12/01/2014

REPORT OF WORK DONE Date Work Completed \_\_\_\_\_

<input type="checkbox"/> Intent to Recomplete (Form 2 also required)	<input type="checkbox"/> Request to Vent or Flare	<input type="checkbox"/> E&P Waste Mangement Plan
<input type="checkbox"/> Change Drilling Plan	<input checked="" type="checkbox"/> Repair Well	<input type="checkbox"/> Beneficial Reuse of E&P Waste
<input type="checkbox"/> Gross Interval Change	<input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request.	
<input type="checkbox"/> Other _____	<input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases	

**COMMENTS:**

- 1) MIRU Workover rig, pump & tank.
- 2) Control well with kill fluid
- 3) POOH 1.66" tubing
- 4) RIH w/ Bit & Scraper. Tag fill if any. Clean out to PBTD (tally in). TOOH
- 5) RIH w/RBP. Set RBP @ +/-6532', spot 2 sx of sand on top of RBP. Test RBP 2,000psi. TOOH
- 6) Bleed off bradenhead, unland casing
- 7) Trip in 1 1/4" tubing down annular w/ mule shoe to +/- 4281', condition hole.
- 8) RU cement crew, pump 201 sxs 13.5ppg FracCem cement covering Sussex, 3681' - 4281' interval cemented.
- 9) TOOH with 1 1/4" tubing to 790', condition hole. POOH to 690'
- 10) RU cement crew, pump 249 sxs 15.8ppg "G" neat cement bringing cement to surface
- 11) Roll hole, POOH with 1 1/4" tubing, land casing.
- 12) SI well overnight, run CBL recording new cement depths
- 13) Clean out hole and consult work schedule for direction regarding leaving plug, setting packer ot changing the wellhead

**CASING AND CEMENTING CHANGES**

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

**H2S REPORTING**

Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.

Gas Analysis Report must be attached.

H2S Concentration: \_\_\_\_\_ in ppm (parts per million) Date of Measurement or Sample Collection \_\_\_\_\_

Description of Sample Point:

Absolute Open Flow Potential \_\_\_\_\_ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: \_\_\_\_\_

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: \_\_\_\_\_

COMMENTS:

### **Best Management Practices**

**No BMP/COA Type**

**Description**

	<b><u>No BMP/COA Type</u></b>	<b><u>Description</u></b>

Operator Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: KATHLEEN MILLS  
Title: REGULATORY ANALYST Email: kmills@nobleenergyinc.com Date: \_\_\_\_\_

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:**

**General Comments**

<b><u>User Group</u></b>	<b><u>Comment</u></b>	<b><u>Comment Date</u></b>

Total: 0 comment(s)

**Attachment Check List**

<b><u>Att Doc Num</u></b>	<b><u>Name</u></b>

Total Attach: 0 Files