

**WORKOVER PROCEDURE**

**WELL NAME:** STATE A36-08 **DATE:** 2/5/2015

**LOCATION:**  
Qtr/Qtr: SE/NE Section: 36 Township: 6N Range: 64W  
Footages: 2080 FNL & 660 FEL

**COUNTY:** WELD **STATE:** CO **API #:** 05-123-14718

**ENGINEER:** DARYL KVEDER 7 Day Notice Sent: \_\_\_\_\_  
(Please notify Engineer of any major Do not start operations until: \_\_\_\_\_  
changes prior to work) Notice Expires: \_\_\_\_\_

**OBJECTIVE:** P&A

**WELL DATA:**  
Surface Csg: 8 5/8" 24# @ 274' KB Elevation: 4216'  
Surface Cmt: 250 sx GL Elevation: 4206'  
Long St Csg: 2 7/8" 6.5# @ 6921' TD: 6945'  
Long St Cmt: 270 sx PBTD: 6819'  
Long St Date: 9/13/1990

Plug Back (Sand or CIBP): \_\_\_\_\_  
Perforation Interval (1): Codell Perforations 6777' - 6788'  
Perforation Interval (2): \_\_\_\_\_  
Perforation Interval (3): \_\_\_\_\_  
Tubing: 1 2/3" 2.33# J-55 tbg @ 6763' Rods: \_\_\_\_\_  
Pump: \_\_\_\_\_  
Misc.: \_\_\_\_\_

**PRODUCTION STATUS:** \_\_\_\_\_  
**COMMENTS:** \_\_\_\_\_

**PROCEDURE:**

- 1) MIRU Workover rig, pump & tank.
- 2) POOH w/ 1 2/3" tbg and lay down.
- 3) RU WL. RIH w/ CIBP. Set CIBP @ 6727', dump bail 2 sx of cement on top.
- 4) RIH w/workstring to 5315'. Pump 5 sx Balance Plug. SI. WOC. Tag plug @ approx. 5000'.
- 5) POOH w/workstring to 4100'. Pump 20 sx Balance Plug. SI. WOC. Tag Plug @ approx. 2000'
- 6) POOH w/ workstring to 750'. Pump 7 sx shoe plug. Cement to surface.
- 7) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
- 8) Cut surface casing off 6'-8' below ground.
- 9) Clean up location. Reclaim location. RDMO.