

State of Colorado  
Oil and Gas Conservation Commission1120 Lincoln Street, Suite 801, Denver, Colorado 80203  
Phone: (303) 894-2100 Fax: (303) 894-2109

DE	ET	OE	ES
Document Number: <b>400799037</b>			
Date Received:			

## SUNDRY NOTICE

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number:	47120	Contact Name	Cheryl Light
Name of Operator:	KERR MCGEE OIL & GAS ONSHORE LP		Phone: (720) 929-6461
Address:	P O BOX 173779		Fax: (720) 929-7461
City:	DENVER	State:	CO Zip: 80217-3779 Email: cheryl.light@anadarko.com

Complete the Attachment  
Checklist

OP OGCC

API Number :	05-	123	10066	00	OGCC Facility ID Number:	242275
Well/Facility Name:	WILLIAM E. GEE GAS UNIT			Well/Facility Number:	2	
Location QtrQtr:	SWSE	Section:	24	Township:	2N	Range: 67W Meridian: 6
County:	WELD		Field Name:	WATTENBERG		
Federal, Indian or State Lease Number:						

Survey Plat		
Directional Survey		
Srfc Eqpmt Diagram		
Technical Info Page		
Other		

## CHANGE OF LOCATION OR AS BUILT GPS REPORT

☐ Change of Location \* ☐ As-Built GPS Location Report ☐ As-Built GPS Location Report with Survey

\* Well location change requires new plat. A substantive surface location change may require new Form 2A.

SURFACE LOCATION GPS DATA Data must be provided for Change of Surface Location and As Built Reports.

Latitude \_\_\_\_\_ PDOP Reading \_\_\_\_\_ Date of Measurement \_\_\_\_\_  
Longitude \_\_\_\_\_ GPS Instrument Operator's Name \_\_\_\_\_

## LOCATION CHANGE (all measurements in Feet)

Well will be: \_\_\_\_\_ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:Change of **Surface** Footage **To** Exterior Section Lines:Current **Surface** Location **From** QtrQtr **SWSE** Sec **24**New **Surface** Location **To** QtrQtr \_\_\_\_\_ Sec \_\_\_\_\_Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:Current **Top of Productive Zone** Location **From** Sec \_\_\_\_\_New **Top of Productive Zone** Location **To** Sec \_\_\_\_\_Change of **Bottomhole** Footage **From** Exterior Section Lines:Change of **Bottomhole** Footage **To** Exterior Section Lines:Current **Bottomhole** Location Sec \_\_\_\_\_ Twp \_\_\_\_\_New **Bottomhole** Location Sec \_\_\_\_\_ Twp \_\_\_\_\_

Is location in High Density Area? \_\_\_\_\_

Distance, in feet, to nearest building \_\_\_\_\_, public road: \_\_\_\_\_, above ground utility: \_\_\_\_\_, railroad: \_\_\_\_\_,  
property line: \_\_\_\_\_, lease line: \_\_\_\_\_, well in same formation: \_\_\_\_\_

Ground Elevation \_\_\_\_\_ feet Surface owner consultation date \_\_\_\_\_

FNL/FSL		FEL/FWL	
1040	FSL	1410	FEL
Twp 2N	Range 67W	Meridian 6	
Twp	Range	Meridian	
			**
Twp	Range		
Twp	Range		
			**
			** attach deviated drilling plan

**CHANGE OR ADD OBJECTIVE FORMATION AND/OR SPACING UNIT**

<u>Objective Formation</u>	<u>Formation Code</u>	<u>Spacing Order Number</u>	<u>Unit Acreage</u>	<u>Unit Configuration</u>

**OTHER CHANGES**

☐ **REMOVE FROM SURFACE BOND** Signed surface use agreement is a required attachment

☐ **CHANGE OF WELL, FACILITY OR OIL & GAS LOCATION NAME OR NUMBER**

From: Name WILLIAM E. GEE GAS UNIT Number 2 Effective Date: \_\_\_\_\_

To: Name \_\_\_\_\_ Number \_\_\_\_\_

☐ **ABANDON PERMIT: Permit can only be abandoned if the permitted operation has NOT been conducted. Field inspection will be conducted to verify site status.**

☐ WELL: Abandon Application for Permit-to-Drill (Form2) – Well API Number \_\_\_\_\_ has not been drilled.

☐ PIT: Abandon Earthen Pit Permit (Form 15) – COGCC Pit Facility ID Number \_\_\_\_\_ has not been constructed (Permitted and constructed pit requires closure per Rule 905)

☐ CENTRALIZED E&P WASTE MANAGEMENT FACILITY: Abandon Centralized E&P Waste Management Facility Permit (Form 28) – Facility ID Number \_\_\_\_\_ has not been constructed (Constructed facility requires closure per Rule 908)

OIL & GAS LOCATION ID Number: \_\_\_\_\_

☐ Abandon Oil & Gas Location Assessment (Form 2A) – Location has not been constructed and site will not be used in the future.

☐ Keep Oil & Gas Location Assessment (Form 2A) active until expiration date. This site will be used in the future.

**Surface disturbance from Oil and Gas Operations must be reclaimed per Rule 1003 and Rule 1004.**

☐ **REQUEST FOR CONFIDENTIAL STATUS**

☐ **DIGITAL WELL LOG UPLOAD**

☐ **DOCUMENTS SUBMITTED** Purpose of Submission: \_\_\_\_\_

**RECLAMATION****INTERIM RECLAMATION**

☐ Interim Reclamation will commence approximately \_\_\_\_\_

Per Rule 1003.e.(3) operator shall submit Sundry Notice reporting interim reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Interim reclamation complete, site ready for inspection.

Per Rule 1003.e(3) describe interim reclamation procedure in Comments below or provide as an attachment and attach required location photographs.

**Field inspection will be conducted to document Rule 1003.e. compliance**

**FINAL RECLAMATION**

☐ Final Reclamation will commence approximately \_\_\_\_\_

Per Rule 1004.c.(4) operator shall submit Sundry Notice reporting final reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Final reclamation complete, site ready for inspection. Per Rule 1004.c(4) describe final reclamation procedure in Comments below or provide as an attachment.

**Field inspection will be conducted to document Rule 1004.c. compliance**

Comments:

## ENGINEERING AND ENVIRONMENTAL WORK

### ☐ NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned \_\_\_\_\_ Has Production Equipment been removed from site? \_\_\_\_\_

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT \_\_\_\_\_

☐ SPUD DATE: \_\_\_\_\_

## TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK

Details of work must be described in full in the COMMENTS below or provided as an attachment.

☒ NOTICE OF INTENT Approximate Start Date 03/11/2015

☐ REPORT OF WORK DONE Date Work Completed \_\_\_\_\_

- |  |   |  |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare   | <input type="checkbox"/> E&P Waste Management Plan     |
| <input type="checkbox"/> Change Drilling Plan                        | <input checked="" type="checkbox"/> Repair Well   | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change                       | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. |  |
| <input type="checkbox"/> Other _____                                 | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases          |  |

## COMMENTS:

1 Well needs Niobrara suicide squeeze and a WH rated to 5000 psi.  
2 Call automation removal group 24 hours before rig up to isolate any production equipment (remove plunger, wellhead automation, etc.). Prepare to move base beam rig onto location. Install fence if needed.  
3 Check and report surface casing pressure. If valve is not accessible at ground level, re-plumb so valve is at ground level.  
4 MIRU slickline. RIH to retrieve production equipment and tag for fill. Last tagged depth on 1/22/2006 was 7934'. Note tagged depth in OpenWells. RDMO slickline.  
5 MIRU WO rig. Kill well as necessary with water and biocide. ND wellhead. NU BOP.  
6 Unland 2-3/8" tbg and lay down landing joint.  
7 MIRU EMI services. EMI 2-3/8" tbg while TOO H and tally while standing back. Lay down joints that have greater than 35% penetration or wall loss. Replace all joints that fail EMI testing. Document joint numbers and depth of bad tubing and create a Production Equipment Failure report in OpenWells. RDMO EMI services.  
8 PU 10,000 psi rated from above and below CIBP (4.5", 11.6#, J-55), and 2-3/8" tubing. Set CIBP at +/- 7,830'.  
9 Release tbg from CIBP and circulate all gas out of the hole. Pumping water with biocide, pressure test CIBP and production casing to 1,000 psi for 15 minutes. If pressure test passes, proceed; otherwise contact engineering.  
10 Bleed off pressure and TOO H standing back all 2 3-8" tbg. Load hole with biocide treated water.  
11 MIRU WL. PU and RIH with CCL-GR-CBL-VDL. Log from tagged CIBP depth (+/- 7,830') to surface. Email results to nicole.schaly@anadarko.com and dave.gomendi@anadarko.com after CBL is ran. No CBL on file, so calculated TOC is 7,246'.  
12 \*\*ALL BELOW STEPS ASSUME TOP OF CEMENT IN WELL AT +/- 7,246'\*\*\*  
13 PU and RIH with 3-1/8" guns and shoot squeeze holes at 7,200' and 6,750' using 3 SPF, 0.42" EHD. RD WL.  
14 PU and TIH with CICR, stinger, and 2-3/8" tbg and set CICR at 6,780'.  
15 MIRU cementing services. Establish injection rate with water and pump 150 sx 50/50 Poz "G" with 20% silica flour, 3% gel, 0.1% sodium metasilicate and 0.4% FL-52 mixed at 13.5 ppg and 1.71 cuft/sx. (cement volumes based on 450' of 9.5" hole with 20% excess and 450' inside 4-1/2" csg with no excess.). Underdisplace cement by 1 bbl short of CICR using 25 bbl of water. Sting out of CICR and PUH 1 stand dumping remaining 1 bbl of cement on top of CICR.  
16 Reverse circulate using approx. 52 bbls water (2 times tubing volume) or until returns are clean. RDMO cementing services.  
17 TOO H and stand back all 2-3/8" tbg. Allow cement to set up for at least 24 hours.  
18 PU and TIH with 3-7/8" blade bit and 2-3/8" tbg to cement top. Drill out cement to CICR and pressure test squeeze holes at 6,750' to 1,000 psi. If pressure test fails contact engineering, otherwise proceed to next step.  
19 Drill out CICR and cement past lower perms at 7,200' and pressure test to 1000 psi. \*\*DON'T DRILL OUT CIBP AT 7,830'\*\*\* If pressure test fails contact engineering, otherwise proceed to next step.  
20 TOO H and stand back all 2-3/8" tubing. LD 3-7/8" bit. Load hole with biocide treated water.  
21 MIRU wireline services. RIH with CCL-GR-CBL-VDL. Log from +/- 7,830' (depth of CIBP) to 100' above TOC (estimated to be +/- 6,750'). If the cement is not above 6,750' contact engineer. RDMO wireline services.  
22 ND BOP.  
23 ND existing tubing head off of 4.5" casing and install new WHI 5,000 psi flanged tubing head complete with 5,000 psi rated casing valves and XXH nipples  
24 NU BOP.  
25 PU and TIH with 3-7/8" blade bit and 2-3/8" tbg to CIBP at +/- 7,830'. Drill out CIBP.  
26 TOO H and stand back all 2-3/8" tubing. LD 3-7/8" bit.  
27 PU 2-3/8" NC, 2-3/8" XN nipple (be sure nipple is correctly input into OpenWells), and 2-3/8" 4.7# J-55 tbg to surface. Land EOT at +/- 7,840' (1 joint above the top J-sand perms).  
29 Install 7-1/1

**CASING AND CEMENTING CHANGES**

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

**H2S REPORTING**

**Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.**

**Gas Analysis Report must be attached.**

H2S Concentration: \_\_\_\_\_ in ppm (parts per million)

Date of Measurement or Sample Collection \_\_\_\_\_

Description of Sample Point:

Absolute Open Flow Potential \_\_\_\_\_ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: \_\_\_\_\_

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: \_\_\_\_\_

COMMENTS:

**Best Management Practices****No BMP/COA Type****Description**

--	--

**Operator Comments:**

29 Install 7-1/16" x 5,000 psi tubing head adaptor with new 5,000 psi master valve with flanged 2-3/8" connection. Make sure all wellhead valves are rated to 5,000 psi.  
30 Install 2-3/8" pup joint above the master valve. Pressure test the tubing head from below the tubing head through the master valve to 5,000 psi using hydrotester.  
31 RDMO WO rig. Return well to production team.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Cheryl Light

Title: Sr. Regulatory Analyst Email: DJRegulatory@anadarko.com Date: \_\_\_\_\_

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:****General Comments**

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
-------------------	----------------	---------------------

--	--	--

Total: 0 comment(s)

**Attachment Check List**

<u>Att Doc Num</u>	<u>Name</u>
--------------------	-------------

400799053	OTHER
-----------	-------

Total Attach: 1 Files