

**WORKOVER PROCEDURE**

**WELL NAME:** BAIER 25-11 **DATE:** 3/2/2015

**LOCATION:**  
Qtr/Qtr: NE/NE/NE Section: 25 Township: 4N Range: 67W  
Footages: 542 FNL & 529 FEL

**COUNTY:** WELD **STATE:** CO **API #:** 05-123-16537

**ENGINEER:** JEREMY GILBERT 7 Day Notice Sent: \_\_\_\_\_  
(Please notify Engineer of any major Do not start operations until: \_\_\_\_\_  
changes prior to work) Notice Expires: \_\_\_\_\_

**OBJECTIVE:** P&A

**WELL DATA:** Surface Csg: 8 5/8" 24# @ 450' KB Elevation: 4765'  
Surface Cmt: 310 sx GL Elevation: 4754'  
Long St Csg: 4 1/2" 15.1# @ 7410' TD: 7410'  
Long St Cmt: 160 sx PBTD: 7360'  
Long St Date: 1/17/1993

Plug Back (Sand or CIBP): \_\_\_\_\_  
Perforation Interval (1): Codell Perforations 7268' - 7281'  
Perforation Interval (2): \_\_\_\_\_  
Perforation Interval (3): \_\_\_\_\_  
Tubing: 2 3/8" ?# ?tbg @ 7248' Rods: \_\_\_\_\_  
Pump: \_\_\_\_\_  
Misc.: \_\_\_\_\_

**PRODUCTION STATUS:** \_\_\_\_\_  
**COMMENTS:** Production Csg Cmt 11' - 3846' ; 6000' - 6700'

**PROCEDURE:**

- 1) MIRU Workover rig, pump & tank.
- 2) POOH w/ 2 3/8" tbg and lay down. Stand back 2500' and lay the rest down.
- 3) RU WL. RIH w/ CIBP. Set CIBP @ 7218', dump bail 2 sx of cement on top.
- 4) RIH w/ workstring to 2500'. Pump 25 sx Balance Plug. SI. WOC. RIH. Tag plug @ approx. 2150'
- 5) POOH w/ workstring to 600'. Pump 47 sx shoe plug. Cement to surface.
- 6) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
- 7) Cut surface casing off 6'-8' below ground.
- 8) Clean up location. Reclaim location. RDMO.