

FORM
6Rev
12/05State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



| | | | |
|-------------------------------|----|----|----|
| DE | ET | OE | ES |
| Document Number: 400802841 | | | |
| Date Received: 03/03/2015 | | | |

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

| | |
|--|----------------------------------|
| OGCC Operator Number: 47120 | Contact Name: Cheryl Light |
| Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP | Phone: (720) 929-6461 |
| Address: P O BOX 173779 | Fax: (720) 929-7461 |
| City: DENVER State: CO Zip: 80217- | Email: cheryl.light@anadarko.com |
| For "Intent" 24 hour notice required, Name: Carlile, Craig Tel: (970) 629-8279 | |
| COGCC contact: Email: craig.carlile@state.co.us | |

| | |
|--|--|
| API Number 05-123-15545-00 | Well Number: 14-15A |
| Well Name: HSR-DENYS | |
| Location: QtrQtr: SESW Section: 15 Township: 3N Range: 67W Meridian: 6 | |
| County: WELD | Federal, Indian or State Lease Number: |
| Field Name: WATTENBERG | Field Number: 90750 |

☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

| | |
|---|--|
| Latitude: 40.219970 | Longitude: -104.879160 |
| GPS Data: | |
| Date of Measurement: 09/27/2006 | PDOP Reading: 2.5 GPS Instrument Operator's Name: Steve Fisher |
| Reason for Abandonment: <input type="checkbox"/> Dry <input checked="" type="checkbox"/> Production for Sub-economic <input type="checkbox"/> Mechanical Problems | |
| <input type="checkbox"/> Other | |
| Casing to be pulled: <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No | Estimated Depth: 900 |
| Fish in Hole: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No | If yes, explain details below |
| Wellbore has Uncemented Casing leaks: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No | If yes, explain details below |
| Details: | |

Current and Previously Abandoned Zones

| Formation | Perf. Top | Perf. Btm | Abandoned Date | Method of Isolation | Plug Depth |
|------------------|-----------|-----------|----------------|---------------------|------------|
| CODELL | 7076 | 7094 | | | |
| J SAND | 7506 | 7564 | | | |
| NIOBRARA | 6820 | 6966 | | | |
| Total: 3 zone(s) | | | | | |

Casing History

| Casing Type | Size of Hole | Size of Casing | Weight Per Foot | Setting Depth | Sacks Cement | Cement Bot | Cement Top | Status |
|-------------|--------------|----------------|-----------------|---------------|--------------|------------|------------|--------|
| SURF | 12+1/4 | 8+5/8 | 24 | 550 | 390 | 550 | 0 | VISU |
| 1ST | 7+7/8 | 4+1/2 | 11.6 | 7,208 | 145 | 7,208 | 6,334 | CBL |
| 1ST LINER | 3+7/8 | 2+7/8 | 6.5 | 7,687 | 21 | 7,687 | 7,143 | CBL |

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7440 with 1 sacks cmt on top. CIPB #2: Depth 6770 with 25 sacks cmt on top.
CIBP #3: Depth 80 with 25 sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 25 sks cmt from 6770 ft. to 6370 ft. Plug Type: CASING Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at 4330 ft. with 300 sacks. Leave at least 100 ft. in casing 3840 CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 240 sacks half in. half out surface casing from 1000 ft. to 450 ft. Plug Tagged: ☒

Set 25 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

5. MIRU, kill as necessary using clean fresh water with biocide. NDWH. NUBOP. Unseat landing jt, LD.

6. Notify cementers to be on call. Provide volumes listed below:

6.1 Niobrara plug: 25 sx (35 cu-ft) "G" w/ 20% silica flour, 0.4% CD-32, 0.4% ASA-301 and R-3 to achieve 2:30 pump time. Mix at 15.8 ppg and 1.38 cu-ft/sk. Cement volume based on 400' in 4 1/2" casing.

6.2 Sussex suicide: 300 sx (345 cu-ft) "G" w/ 0.25 pps cello flake, 0.4% CD-32, 0.4% ASA-301, mixed at 15.8 ppg and 1.15 cu-ft/sk. Cement volume based on 720' in 4 1/2" casing and 520' in a 10" OH with 20% excess. Caliper on file.

6.3 Foxhills plug: 240 sx (319 cu-ft) Type III w/ cello flake and CaCl2 as necessary, mixed at 14.8 ppg and 1.33 cu-ft/sk. Cement volume based on 100' in 4 1/2" casing, 350' in a 10" OH with 20% excess, and 200' in 8 5/8" casing. Caliper on file.

7. TOOH 2 3/8" and 1.66" tubing landed at 7480'. Stand back 2 3/8" tubing and lay down 1.66" tubing.

8. MIRU WL. RIH gauge ring for 2 7/8" 6.5# casing to 7500'. POOH.

9. PU 2 7/8" 6.5# CIBP and RIH w/ WL. Set at +/-7440' to abandon J Sand perfs. PU dump bailer, dump bail 1 sx class "G" cement on CIBP. POOH.

10. RIH gauge ring for 4 1/2" 11.6# casing to 6800'. POOH.

11. PU 4 1/2" 11.6# CIBP and RIH w/ WL. Set at +/-6770' to abandon Niobrara and Codell perfs. PT to 1000 psi for 15 minutes. RDMO WL.

12. RIH with 2 3/8" tubing to +/- 6770', tag CIBP and PUH 5'. Hydrotest tubing to 3000 psi while RIH.

13. RU cementers. Pump Niobrara plug: 25 sx (35 cu-ft) "G" w/ 20% silica flour, 0.4% CD-32, 0.4% ASA-301 and R-3 to achieve 2:30 pump time. Mix at 15.8 ppg and 1.38 cu-ft/sk. Plug to cover 6370' - 6770'.

14. PUH to +/- 6100'. Reverse circulate with biocide treated water to displace cement and clear tubing.

15. POOH. Stand back 3840' of tubing.

16. RU WL. PU 3 1/8" perf guns with 3 spf, 120 degree phasing, 0.50" EHD and RIH w/ WL. Shoot 1' of squeeze holes at 4330' and 2' of squeeze holes at 3810'. RD WL.

17. PU and RIH w/CICR and 2 3/8" tubing, set CICR at +/- 3840'. Establish circulation with rig pump using biocide treated water.

18. RU cementers. Establish circulation with biocide treated water and precede cement with 5 bbl water containing biocide, 20 bbl sodium metasilicate and another 5 bbl water spacer.

19. Pump Sussex suicide: 300 sx (345 cu-ft) "G" w/ 0.25 pps cello flake, 0.4% CD-32, 0.4% ASA-301, mixed at 15.8 ppg and 1.15 cu-ft/sk to place cement between perfs from 4330' to 3810'. Under displace and sting out of CICR to leave 3 bbls (~200') on top of retainer. Cement volume based on 10" OH with 20% excess. Caliper readings across entire interval. RD cementers.

20. PUH to +/- 3400'. Reverse circulate with biocide treated water to displace cement and clear tubing.

21. P&SB 1000', LD remainder.

22. RU WL. Shoot off 4 1/2" casing at or below 900'. RD WL. Circulate casing with biocide treated water to remove any gas.

23. NDBOP, NDTH.

24. Install BOP on casing head with 4 1/2" pipe rams.

25. TOOH 4 1/2" casing, LD.

26. RIH with 2 3/8" tubing to 1000' inside 4 1/2" casing.

27. RU cementers. Establish circulation with biocide treated water and precede cement with 10 bbl SAPP and a minimum 20 bbl fresh water spacer. Pump Foxhills plug: 240 sx (319 cu-ft) Type III w/ cello flake and CaCl2 as necessary, mixed at 14.8 ppg and 1.33 cu-ft/sk. Plug to cover 1000' - 900' in 4 1/2" casing, 900' - 550' in 10" OH with 20% excess, and 550' - 350' in 8 5/8" casing. Caliper readings across entire interval. RD cementers.

28. PUH to 100' and circulate with biocide treated water to displace cement and clear tubing.

29. WOC per cement company recommendation. Tag cement at or above 450'. If not, consult with Evans Engineering.

30. RU WL. RIH 8 5/8" 24# CIBP to 80'. Set and pressure test to 1000 psi for 15 minutes. If tests, RDMO WL and WO rig.

31. Instruct cementing and wireline contractors to email copies of all job logs/jobs summaries to rscDJVendors@anadarko.com within 24 hours of completion of the job.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Cheryl Light
 Title: Sr. Regulatory Analyst Date: 3/3/2015 Email: cheryl.light@anadarko.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SCHLAGENHAUF, MARK Date: 3/14/2015

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: 9/13/2015

COA Type

Description

| | |
|--|---|
| | 1) Submit Form 42 electronically to COGCC 48 hours prior to MIRU. 2) If unable to pull casing contact COGCC for plugging modifications. 3) For 1000' plug: pump plug and displace, shut-in, WOC 4 hours and tag plug - must be 500' or shallower. 4) Properly abandon flowlines as per Rule 1103. File electronic Form 42 once abandonment complete. 5) Please submit existing gyro survey data with Form 6 (s) Subsequent Report of Abandonment. |
|--|---|

Attachment Check List

Att Doc Num**Name**

| | |
|-----------|-----------------------------|
| 400802841 | FORM 6 INTENT SUBMITTED |
| 400802844 | PROPOSED PLUGGING PROCEDURE |
| 400802845 | WELLBORE DIAGRAM |

Total Attach: 3 Files

General Comments

User Group**Comment****Comment Date**

| | | |
|--------|--|------------------------|
| Permit | Well Completion Report dated 5/5/1992 & 4/11/2003. | 3/5/2015 1:30:46 PM |
|--------|--|------------------------|

Total: 1 comment(s)