

**WORKOVER PROCEDURE**

**WELL NAME:** Stromberger Federal 34-12 **DATE:** 8/3/2015

**LOCATION:**  
Qtr/Qtr: SW/SE Section: 12 Township: 4N Range: 66W  
Footages: 800' FSL & 2,182' FEL

**COUNTY:** WELD **STATE:** CO **API #:** 05-123-16460

**ENGINEER:** Hilary Ramseier **7 Day Notice Sent:** \_\_\_\_\_  
(Please notify Engineer of any major changes prior to work) **Do not start operations until:** \_\_\_\_\_  
**Notice Expires:** \_\_\_\_\_

**OBJECTIVE:** P&A

**WELL DATA:** Surface Csg: 8-5/8" 24# @ 282' KB Elevation: 4,723'  
Surface Cmt: 285 sx GL Elevation: 4,713'  
Long St Csg: 4-1/2" 11.6# @ 7,299' TD: 7,300'  
Long St Cmt: 285 sx PBTD: 7,271'  
Long St Date: 11/30/1992

Plug Back (Sand or CIBP): \_\_\_\_\_  
Perforation Interval (1): Niobrara Perforations 6,872' - 7,002'  
Perforation Interval (2): Codell Perforations 7,176' - 7,186'  
Perforation Interval (3): \_\_\_\_\_  
Tubing: 2-3/8" @ 7105' Rods: \_\_\_\_\_  
Pump: \_\_\_\_\_  
Misc.: \_\_\_\_\_

**PRODUCTION STATUS:** Currently producing 1 bopd and 20 mcf. Pressures currently 338/356  
**COMMENTS:** \_\_\_\_\_

**PROCEDURE:**

- 1) MIRU Workover rig, pump & tank.
- 2) POOH w/ 2 3/8" tbg and lay down.
- 3) RU WL. RIH w/ CIBP. Set CIBP @ 6,822', dump bail 2 sx of cement on top.
- 4) RIH w/ workstring. Pump 80 sx balance plug @ 4,955'. This is to cover existing cement that covers the Sussex.
- 5) Unland casing. Cut casing off @ 2500'. POOH with casing laying down on trailer.
- 7) RIH w/ workstring to pump 100 sx stub plug where csg was pulled. If maintain circulation, no need to tag plug.
- 8) POOH w/ workstring to 385'. Pump 150 sx shoe plug. Cement to surface.
- 9) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
- 10) Cut surface casing off 6'-8' below ground.
- 11) Clean up location. Reclaim location. RDMO.