

WORKOVER PROCEDURE

WELL NAME: Wind #17-23 DATE: 8/26/2015

LOCATION: Qtr/Qtr: SESW Section: 17 Township: 4N Range: 67W

COUNTY: Weld STATE: CO API #: 05-123-36437

ENGINEER: 7 Day Notice Sent: (Please notify Engineer of any major changes prior to work) Do not start operations until: Notice Expires:

OBJECTIVE: Plug & Abandon

WELL DATA: Surface Csg: 8 5/8" 24# @ 689' KB Elevation: 4855' Surface Cmt: 450 sacks cement GL Elevation: 4841' Long St Csg: 4.5' 11.6# @ 7530' TD: 7563' Long St Cmt: 510 sacks cement, TOC @ 2700' PBDT: 7530' Long St Date:

Plug Info (1) CIBP @ 7350' w/ 2sx on top Plug Info (2) 800' - Surface w/ 325sx - 75sx in, 250sx out Plug Info (3)

Tubing: 2 3/8" @ 7386' Rods: Pump: Misc.: Codell: 7420' - 7400'

WELL STATUS:

COMMENTS: Spud Date: 4/29/2013

PROCEDURE:

- 1) MIRU and blow well down. 2) Pull tubing out of hole. 3) RIH with CIBP set @ 7350' with 2sx Class G cement on top. 5) Cut surface casing 5' below surface. 6) Pump 325sx @ 800', 75sx in, 250sx out. 7) RDMO. 8) Weld cap on and reclaim surface.