

WORKOVER PROCEDURE

WELL NAME: Wind #17-21 DATE: 7/30/2015

LOCATION: Qtr/Qtr: SENW Section: 17 Township: 4N Range: 67W
COUNTY: Weld STATE: CO API #: 05-123-36548

ENGINEER: 7 Day Notice Sent:
(Please notify Engineer of any major changes prior to work) Do not start operations until:
Notice Expires:

OBJECTIVE: Plug & Abandon

WELL DATA: Surface Csg: 8 5/8" 24# @ 689' KB Elevation: 4808'
Surface Cmt: 450 sacks cement GL Elevation: 4794'
Long St Csg: 4.5" 11.6# @ 7414' TD: 7398'
Long St Cmt: 520 sacks cement - TOC @ 2650 CBL PBDT: 7356'
Long St Date:

Plug Info (1) CIBP @ 7204' w/ 2sx on top
Plug Info (2) 800' - Surface w/ 325sx - 75sx in, 250sx out
Plug Info (3)

Tubing: 2 3/8" @ 7222' Rods:
Pump:
Misc.: Codell: 7234' - 7254'

WELL STATUS:

COMMENTS: Spud Date: 4/25/2013

PROCEDURE:

- 1) MIRU and blow well down.
2) RIH with CIBP set @ 7204' with 2sx Class G cement on top.
3) Cut surface casing 5' below surface.
4) Pump 325sx @800', 75sx in, 250sx out.
5) RDMO.
6) Weld cap on and reclaim surface.