

**WORKOVER PROCEDURE**

**WELL NAME:** Dinner K 13-2 **DATE:** 11/18/2015

**LOCATION:**

Qtr/Qtr: NWNE Section: 13 Township: 4N Range: 66W  
Footages: 662 FNL & 2042 FEL

**COUNTY:** WELD **STATE:** CO **API #:** 05-123-16641

**ENGINEER:** AJ Paine 7 Day Notice Sent: \_\_\_\_\_  
(Please notify Engineer of any major Do not start operations until: \_\_\_\_\_  
changes prior to work) Notice Expires: \_\_\_\_\_

**OBJECTIVE:** P&A

**WELL DATA:** Surface Csg: 8 5/8", 24# @ 327' KB Elevation: 4743'  
Surface Cmt: 240 sx GL Elevation: 4733'  
Long St Csg: 2 7/8", 6.5#, N-80 @ 7427' TD: 7449'  
Long St Cmt: 225+210 sx PBTD: 7408'  
Long St Date: 1/6/1993

Plug Back (Sand or CIBP): **Sand**  
Perforation Interval (1): Codell Perforations: 7196' - 7206'  
Perforation Interval (2): \_\_\_\_\_  
Perforation Interval (3): \_\_\_\_\_  
Tubing: \_\_\_\_\_ Rods: \_\_\_\_\_  
Pump: \_\_\_\_\_  
Misc.: Casing Patch (2003): 2 7/8", 6.5#, N-80, surface - 3644'

**PRODUCTION STATUS:** Producing 10 mcfd and 0.2 bopd up 2 7/8" casing. 420 psi on casing. No tubing installed.  
**COMMENTS:** Can't payout tubing install and annular fill.

**PROCEDURE:**

- 1) MIRU Workover rig, pump & tank.
- 2) RU WL. RIH w/ CIBP. Set CIBP @ 7146'.
- 3) RIH w/ workstring. Pump 10 sx balance plug from 6970' - 6620' to cover the Niobrara.
- 4) POOH w/ workstring to pump 30 sx balance plug from 4750' - 3750' to cover Sussex.
- 5) Unland 2 7/8" casing. Cut casing off @ 2500'. POOH and laydown casing.
- 6) RIH w/ workstring to pump 100 sx stub plug where casing was pulled. If maintain circulation, no need to tag plug.
- 7) POOH w/ workstring to 427'. Pump 150 sx shoe plug. Cement to surface.
- 8) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
- 9) Cut surface casing off 6'-8' below ground.
- 10) Clean up location. Reclaim location. RDMO.