

### WORKOVER PROCEDURE

**WELL NAME:** Houndskeeper H01-22 **DATE:** 12/8/2015

**LOCATION:** Qtr/Qtr: SE/NE Section: 1 Township: 3N Range: 65W

Footages: 2490' FNL & 1270' FEL

**COUNTY:** WELD **STATE:** CO **API #:** 05-123-27129

**ENGINEER:** Benjamin Daniell 7 Day Notice Sent: \_\_\_\_\_

(Please notify Engineer of any major Do not start operations until: \_\_\_\_\_

changes prior to work) Notice Expires: \_\_\_\_\_

**OBJECTIVE:** P&A

**WELL DATA:** Surface Csg: 8 5/8" 24# J-55 @ 688' KB Elevation: 4884'

Surface Cmt: 319 sx GL Elevation: 4871'

Long St Csg: 4 1/2" 11.6# M-80 @ 7270' TD: 7272'

Long St Cmt: 760 sx PBDT: 7249'

Long St Date: 10/8/2008

Plug Back (Sand or CIBP): \_\_\_\_\_

Perforation Interval (1): Niobrara Perforations 6838' - 6913'

Perforation Interval (2): Codell Perforations 7114' - 7128'

Perforation Interval (3): \_\_\_\_\_

Tubing: 2-3/8" @ 7075' Rods: NA

Pump: NA

Misc.: \_\_\_\_\_

**PRODUCTION STATUS:** Producing

**COMMENTS:** Doesn't cover CR49 expansion; producing Sussex within 1 mile

**PROCEDURE:**

- 1) MIRU Workover rig, pump & tank.
- 2) POOH w/ 2 3/8" tbg and lay down.
- 3) RU WL. RIH w/ CIBP. Set CIBP @ 6788', dump bail 2 sx of cement on top.
- 4) RIH w/ workstring to pump 30 sx balance plug @ 4500' due to producing Sussex within 1 mile. If maintain circulation, nc
- 5) Unland casing. Cut casing off @ 1350'. POOH with casing laying down on trailer.
- 6) RIH w/ workstring to pump 100 sx stub plug where csg was pulled. If maintain circulation, no need to tag plug.
- 7) POOH w/ workstring to 788'. Pump 260 sx shoe plug. Cement to surface.
- 8) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
- 9) Cut surface casing off 6'-8' below ground.
- 10) Clean up location. Reclaim location. RDMO.