

WORKOVER PROCEDURE

| | | | | | | | |
|---------------------------|---|----------|---------------|--------------------------------|---------------|---------------|--------------|
| WELL NAME: | Victor G 14-12 | | | DATE: | 4/11/2016 | | |
| LOCATION: | | | | | | | |
| Qtr/Qtr: | NWSW | Section: | 14 | Township: | 4N | Range: | 65W |
| Footages: | 1980 FSL | | & | 660 FWL | | | |
| COUNTY: | WELD | | STATE: | CO | | API #: | 05-123-14651 |
| ENGINEER: | Garrett Reddin | | | 7 Day Notice Sent: | | | |
| | (Please notify Engineer of any major changes prior to work) | | | Do not start operations until: | | | |
| | | | | Notice Expires: | | | |
| OBJECTIVE: | P&A | | | | | | |
| WELL DATA: | | | | | | | |
| Surface Csg: | 8-5/8" 24# @ 385' KB | | | | KB Elevation: | 4704' | |
| Surface Cmt: | 270 sx | | | | GL Elevation: | 4694' | |
| Long St Csg: | 4-1/2" 10.5# @ 4538' KB | | | | TD: | 4538' KB | |
| Long St Cmt: | 250 sx | | | | PBTD: | 4472' KB | |
| Long St Date: | 11/13/1990 | | | | | | |
| Plug Back (Sand or CIBP): | | | | | | | |
| Perforation Interval (1): | Sussex Perforations: 4390-4405' | | | | | | |
| Perforation Interval (2): | | | | | | | |
| Perforation Interval (3): | | | | | | | |
| Tubing: | 2-3/8" 4.7# J-55 @ 4216' KB | | | | Rods: | | |
| Pump: | | | | | | | |
| Misc.: | | | | | | | |
| PRODUCTION STATUS: | SI | | | | | | |
| COMMENTS: | Well was producing large amounts of rubber | | | | | | |

PROCEDURE:

- 1) MIRU Workover rig, pump & tank.
- 2) POOH w/ 2 3/8" tbg and lay down.
- 3) RU WL. RIH w/ CIBP. Set CIBP @ 4340', dump bail 2 sx of cement on top.
- 4) Unland casing. Cut casing off @ 2500'. POOH with casing laying down on trailer.
- 5) RIH w/ workstring to pump 100 sx stub plug where csg was pulled. If maintain circulation, no need to tag plug.
- 6) POOH w/ workstring to 485'. Pump 190 sx shoe plug. Cement to surface.
- 7) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
- 8) Cut surface casing off 6'-8' below ground.
- 9) Clean up location. Reclaim location. RDMO.