

**WORKOVER PROCEDURE**

**WELL NAME:** Cervi USX CC15-09 **DATE:** 5/16/2016

**LOCATION:** Qtr/Qtr: NESE Section: 15 Township: 4N Range: 63W

Footages: 1980 FSL & 660 Township: 4N Range: 63W  
1980 FSL & 660 Township: 4N Range: 63W

**COUNTY:** WELD **STATE:** CO **API #:** 05-123-26005

**ENGINEER:** AJ Paine 7 Day Notice Sent: \_\_\_\_\_  
(Please notify Engineer of any major Do not start operations until: \_\_\_\_\_  
changes prior to work) Notice Expires: \_\_\_\_\_

**OBJECTIVE:** P&A

**WELL DATA:** Surface Csg: 8 5/8", 24#, J55 @ 483' KB Elevation: 4688'  
Surface Cmt: 233 sx GL Elevation: 4672'  
Long St Csg: 4 1/2", 11.6#, M-80 @ 7451' TD: 7451'  
Long St Cmt: 780 sx PBTB: 7415'  
Long St Date: 10/9/2007

Plug Back (Sand or CIBP): Fill  
Perforation Interval (1): Dakota Perforations: 7322' - 7338'  
Perforation Interval (2): \_\_\_\_\_  
Perforation Interval (3): \_\_\_\_\_  
Tubing: 2 3/8", 4.7#, J-55 @ 7302' Rods: \_\_\_\_\_  
Pump: \_\_\_\_\_  
Misc.: SN and notched collar @ EOT

**PRODUCTION STATUS:** SI since October 2014.

**COMMENTS:** \_\_\_\_\_

**PROCEDURE:**

- 1) MIRU Workover rig, pump & tank.
- 2) POOH and laydown 2 3/8" tubing.
- 3) RU WL. RIH to tag CIBP or fill. PBTB @ 7415' in 2007.
- 4) RIH w/ CIBP. Set @ 7272'.
- 5) RIH w/ workstring to pump 85 sx balance plug from CIBP to 6190' to cover Niobrara top.
- 6) Unland casing. Cut casing off @ 2000'. POOH and laydown 4 1/2" casing.
- 7) RIH w/ workstring to pump 100 sx stub plug where casing was pulled. If maintain circulation, no need to tag plug.
- 8) POOH w/ workstring to 583'. Pump 205 sx shoe plug. Cement to surface.
- 9) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
- 10) Cut surface casing off 6'-8' below ground.
- 11) Clean up location. Reclaim location. RDMO.