



**CHANGE OR ADD OBJECTIVE FORMATION AND/OR SPACING UNIT**

<u>Objective Formation</u>	<u>Formation Code</u>	<u>Spacing Order Number</u>	<u>Unit Acreage</u>	<u>Unit Configuration</u>

**OTHER CHANGES**

☐ **REMOVE FROM SURFACE BOND** Signed surface use agreement is a required attachment

☐ **CHANGE OF WELL, FACILITY OR OIL & GAS LOCATION NAME OR NUMBER**

From: Name CARLSON K Number 23-22D Effective Date: \_\_\_\_\_

To: Name \_\_\_\_\_ Number \_\_\_\_\_

☐ **ABANDON PERMIT: Permit can only be abandoned if the permitted operation has NOT been conducted. Field inspection will be conducted to verify site status.**

☐ WELL: Abandon Application for Permit-to-Drill (Form2) – Well API Number \_\_\_\_\_ has not been drilled.

☐ PIT: Abandon Earthen Pit Permit (Form 15) – COGCC Pit Facility ID Number \_\_\_\_\_ has not been constructed (Permitted and constructed pit requires closure per Rule 905)

☐ CENTRALIZED E&P WASTE MANAGEMENT FACILITY: Abandon Centralized E&P Waste Management Facility Permit (Form 28) – Facility ID Number \_\_\_\_\_ has not been constructed (Constructed facility requires closure per Rule 908)

OIL & GAS LOCATION ID Number: \_\_\_\_\_

☐ Abandon Oil & Gas Location Assessment (Form 2A) – Location has not been constructed and site will not be used in the future.

☐ Keep Oil & Gas Location Assessment (Form 2A) active until expiration date. This site will be used in the future.

**Surface disturbance from Oil and Gas Operations must be reclaimed per Rule 1003 and Rule 1004.**

☐ **REQUEST FOR CONFIDENTIAL STATUS**

☐ **DIGITAL WELL LOG UPLOAD**

☐ **DOCUMENTS SUBMITTED** Purpose of Submission: \_\_\_\_\_

**RECLAMATION****INTERIM RECLAMATION**

☐ Interim Reclamation will commence approximately \_\_\_\_\_

Per Rule 1003.e.(3) operator shall submit Sundry Notice reporting interim reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Interim reclamation complete, site ready for inspection.

Per Rule 1003.e(3) describe interim reclamation procedure in Comments below or provide as an attachment and attach required location photographs.

**Field inspection will be conducted to document Rule 1003.e. compliance**

**FINAL RECLAMATION**

☐ Final Reclamation will commence approximately \_\_\_\_\_

Per Rule 1004.c.(4) operator shall submit Sundry Notice reporting final reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Final reclamation complete, site ready for inspection. Per Rule 1004.c(4) describe final reclamation procedure in Comments below or provide as an attachment.

**Field inspection will be conducted to document Rule 1004.c. compliance**

Comments:

## ENGINEERING AND ENVIRONMENTAL WORK

### ☐ NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned \_\_\_\_\_ Has Production Equipment been removed from site? \_\_\_\_\_

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT \_\_\_\_\_

☐ SPUD DATE: \_\_\_\_\_

## TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK

Details of work must be described in full in the COMMENTS below or provided as an attachment.

☒ NOTICE OF INTENT Approximate Start Date 10/15/2016

☐ REPORT OF WORK DONE Date Work Completed \_\_\_\_\_

- |  |   |  |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare   | <input type="checkbox"/> E&P Waste Mangement Plan      |
| <input type="checkbox"/> Change Drilling Plan                        | <input checked="" type="checkbox"/> Repair Well   | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change                       | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. |  |
| <input type="checkbox"/> Other _____                                 | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases          |  |

## COMMENTS:

- 1) MIRU workover rig, pump and truck.
- 2) Control well with kill fluid.
- 3) PU 2-3/8" tubing and tag fill. POOH and lay down to inspect pin heads.
- 4) RIH w/ bit and scraper. Clean out to PBTD (tally in). TOOH.
- 5) RIH w/ RBP. Set RBP @ 7,000', spot 2 sx sand on top.
- 6) Test casing to 2000 psi. If pressure test is good, proceed to Step 7. If pressure test fails, check RBP is good. If RBP is good, begin hole hunting and call office.
- 7) Bleed off bradenhead. Unland casing and NU 4-1/2" x 2-3/8" adapter flange (bradenhead pressure exists, caution when RIH, establish circulation to control well).
- 8) Run down annulus with 1-1/4" tubing to 1,650'. Condition hole with 2x volume of 9.5# mud.
- 9) Preference is to have pop-offs set at 2,000 psig to avoid breaking down the formation (Base of Upper Pierre @ 1,383'). If pop offs need to be set higher, confirm that the rig is seeing full returns and call office.
- 10) RU HES. RIH to 1,650' and set 10 bbl viscous balance plug using 15.8 ppg Tuned Spacer III.
- 11) POOH to 1,400'. Pump cement design from 1,400' to 800'.
  - a) Pump 10 bbl of Mud Flush III.
  - b) Pump 175 sx 15.8 ppg PlugCem. Cement from 1,400' to 800'.
- 12) POOH to 700' and roll hole to ensure TOC is ~800'. If cannot circulate, immediately POOH to above cement.
- 13) POOH w/ 1-1/4" tubing, land casing.
- 14) SI well overnight. Monitor surface casing pressure, call office if pressure remains.
- 15) Run CBL recording new cement depths.
- 16) RIH w/ retrieving head to 6,970' and circulate hole 2x hole volume to clean sand off top of RBP.
- 17) Continue to RIH to 7,000', latch on to RBP and POOH.
- 18) Hydrotest and tally back in hole with 2-3/8" tubing, notched collar, SN.  
Replace bad joints as required with 2.33#, J-55 2-3/8" tubing  
Land with SN @ 7,395' (+/-20' above Codell perms)
- 19) Flange wellhead up for continued production after rig off.
- 20) RDMO workover rig, pump and tank.

## CASING AND CEMENTING CHANGES

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

## H2S REPORTING

Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.

Gas Analysis Report must be attached.

H2S Concentration: \_\_\_\_\_ in ppm (parts per million)

Date of Measurement or Sample Collection \_\_\_\_\_

Description of Sample Point:

--

Absolute Open Flow Potential \_\_\_\_\_ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

--

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: \_\_\_\_\_

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: \_\_\_\_\_

COMMENTS:

--

## Best Management Practices

No BMP/COA Type

Description

--	--

**Operator Comments:**

--

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Julie Webb

Title: Senior Regulatory Analyst Email: jwebb@progressivepcs.net Date: \_\_\_\_\_

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:****COA Type****Description**

------	------

**General Comments****User Group****Comment****Comment Date**

------	------	------

Total: 0 comment(s)

**Attachment Check List****Att Doc Num****Name**

------	------

Total Attach: 0 Files