

WORKOVER PROCEDURE

WELL NAME: Fritzler 25-22 **DATE:** 10/5/2016
LOCATION:
Qtr/Qtr: SWNE Section: 22 Township: 4N Range: 66W
Footages: 2,356' FNL & 2,405' FWL
COUNTY: WELD **STATE:** CO **API #:** 05-123-25842

ENGINEER: Jeanne Van Slambrouck 7 Day Notice Sent: _____
(Please notify Engineer of any major Do not start operations until: _____
changes prior to work) Notice Expires: _____

OBJECTIVE: P&A

WELL DATA: Surface Csg: 8-5/8", 24#, J-55 @ 775' KB Elevation: 4752'
Surface Cmt: 296 sx GL Elevation: 4736'
Long St Csg: 4-1/2", 11.60#, I-80 @ 7,488' TD: 7500'
Long St Cmt: 850 sx PBTD: 7472'
Long St Date: 12/9/2008

Plug Back (Sand or CIBP): sand
Perforation Interval (1): Niobrara Perforations: 7034' - 7228'
Perforation Interval (2): Codell Perforations: 7337' - 7352'
Perforation Interval (3): _____
Tubing: 2-3/8", 4.70#, J-55 @ 7327' Rods: _____
Pump: _____
Misc.: _____

PRODUCTION STATUS: Currently Producing, 312# / 326#
COMMENTS: Uneconomic to do annular fill

PROCEDURE:

- 1) MIRU Workover rig, pump & tank.
- 2) POOH w/ 2-3/8" tbg and lay down.
- 3) RU WL. RIH w/ CIBP. Set CIBP @ 6984', dump bail 2 sx of cement on top.
- 4) RIH w/ work string to pump 25 sx balance plug across the Sussex @ 4332' - 4632'
- 5) Unland 4-1/2" casing. Cut casing off @ 2000'. POOH w/ casing laying down on trailer.
- 6) RIH w/ workstring. Pump 100 sx stub plug where casing was pulled.
- 7) POOH w/ workstring to pump 331 sx shoe plug @ 875'. Cement to surface.
- 8) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
- 9) Cut surface casing off 6'-8' below ground.
- 10) Clean up location. Reclaim location. RDMO.