

WORKOVER PROCEDURE

WELL NAME:	Cannon H35-21		DATE:	11/16/2016			
LOCATION:							
Qtr/Qtr:	NW/SE	Section:	35	Township:	3N	Range:	65W
Footages:	2499'	FSL	&	2497'	FEL		
COUNTY:	WELD		STATE:	CO		API #:	05-123-31878
ENGINEER:	Baxter Whittington			7 Day Notice Sent:			
	(Please notify Engineer of any major changes prior to work)			Do not start operations until:			
				Notice Expires:			
OBJECTIVE:	P&A						
WELL DATA:							
Surface Csg:	8 5/8" 24# J-55 @ 747'				KB Elevation:	4863'	
Surface Cmt:	300 sx				GL Elevation:	4850'	
Long St Csg:	4 1/2" 11.6# M-80 @ 7748'				TD:	7760'	
Long St Cmt:	695 sx				PBTD:	7702'	
Long St Date:	7/20/2011						
Plug Back (Sand or CIBP):	TBG Tally @ 7702'						
Perforation Interval (1):	Nio Perforations 6902' - 7022'						
Perforation Interval (2):	Codell Perforations 7144' - 7156'						
Perforation Interval (3):	J Sand Perforations 7606' - 7636'						
Tubing:	2-3/8" @ 7585'		Rods:		NA		
Pump:	NA						
Misc.:							
PRODUCTION STATUS:	PR						
COMMENTS:	Bradenhead						

PROCEDURE: SEE COA ON APPROVED PROCEDURE

- 1) MIRU Workover rig, pump & tank.
- 2) Unland 2 3/8" tbq. POOH w/ 2 3/8" tbq and lay down.
- 3) RU WL. RIH w/ CIBP. Set CIBP @ 7555', dump bail 2 sx of cement on top.
- 4) RIH w/ CIBP. Set CIBP @ 6850', dump bail 2 sx of cement on top.
- 5) RIH w/ workstring to pump 54 sx balanced plug @ 5000' to cover Sussex (ETOC= 4300').
- 6) POOH to 2500' to pump 20 sk courtesy plug from 2500' - 2235'.
- 7) Unland casing. Cut casing off @ 1350'. POOH with casing laying down on trailer.
- 8) RIH w/ workstring to pump 100 sx stub plug at 1400' (min. 50' inside casing). If maintain circulation, no need to tag plug.
- 9) POOH w/ workstring to 860'. Pump 280 sx shoe plug. Cement to surface.
- 10) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
- 11) Cut surface casing off 6'-8' below ground.
- 12) Clean up location. Reclaim location. RDMO.