

Document Number:
401172105

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: JEnifer Hakkarinen
 Name of Operator: PDC ENERGY INC Phone: (303) 8605800
 Address: 1775 SHERMAN STREET - STE 3000 Fax: _____
 City: DENVER State: CO Zip: 80203 Email: Jenifer.Hakkarinen@pdce.com

For "Intent" 24 hour notice required, Name: _____ Tel: _____
 COGCC contact: Email: _____

API Number 05-123-21965-00 Well Number: 23-36
 Well Name: STATE CORSAIR
 Location: QtrQtr: NESW Section: 36 Township: 4N Range: 68W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.268810 Longitude: -104.953670
 GPS Data:
 Date of Measurement: 09/26/2006 PDOP Reading: 2.2 GPS Instrument Operator's Name: Holly L. Tracy
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

| Formation | Perf. Top | Perf. Btm | Abandoned Date | Method of Isolation | Plug Depth |
|------------------|-----------|-----------|----------------|---------------------|------------|
| CODELL | 7336 | 7344 | 12/15/2016 | B PLUG CEMENT TOP | 7286 |
| Total: 1 zone(s) | | | | | |

Casing History

| Casing Type | Size of Hole | Size of Casing | Weight Per Foot | Setting Depth | Sacks Cement | Cement Bot | Cement Top | Status |
|-------------|--------------|----------------|-----------------|---------------|--------------|------------|------------|--------|
| SURF | 12+1/4 | 8+5/8 | 24 | 400 | 225 | 400 | 0 | VISU |
| 1ST | 7+7/8 | 4+1/2 | 10.5 | 7,535 | 190 | 7,535 | 6,380 | CBL |

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7286 with 2 sacks cmt on top. CIBP #2: Depth 6990 with 2 sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 155 sks cmt from 703 ft. to 0 ft. Plug Type: STUB PLUG Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: 600 ft. of 4+1/2 inch casing Plugging Date: 12/15/2016

*Wireline Contractor: Nabors *Cementing Contractor: Ranger

Type of Cement and Additives Used: 15.8 ppg class G cement

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

State Corsair #23-36 (05-123-21965)/Plugging Procedure
Producing formation: Codell
Existing Perforations: Codell - 7,336'-7,344'
TD: 7,560' PBTD: 7,521'
Surface Casing: 8 5/8" 24# @ 400' w/ 225 sks cmt.
Production Casing: 4 1/2" 10.5# @ 7,535' w/ 190 sks cmt (TOC at 6,380').

Procedure:

1. MIRU pulling unit.
2. Blow down to tanks. Load with fluid to kill well.
3. Circulate and condition well for P&A ops.
4. TOOH with 235 jts of 2 3/8" production tubing.
5. Rig up wireline. RIH with CIBP. Set CIBP at 7286'.
6. Load dump bailer with 2sx of 15.8#/gal CI G cement. RIH with dump bailer and spot on top of CIBP.
7. RIH with CIBP. Set CIBP at 6990'.
8. Load dump bailer with 2sx of 15.8#/gal CI G cement. RIH with dump bailer and spot on top of CIBP.
9. RIH w/ casing cutter and cut production casing above TOC at 600'. Pull 4 1/2" casing out of hole.
10. TIH with workstring to 703'. Circulate and condition to prepare for surface plug.
11. RU cementers. Mix and pump cement stub plug to surface (703') with 155 sks of 15.8#/gal CL G cement. cement to surface.
12. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____

Print Name: Jenifer Hakkarinen

Title: Reg Tech

Date: _____

Email: Jenifer.Hakkarinen@pdce.com

