

Engineer: Alex Caravaggio
213-880-8119

Retainer Suicide Squeeze (Bradenhead)

BULTHAUP 24-6

- 1 Well needs a retainer squeeze from 950'-480' for bradenhead issue, as well as a packer.
- 2 Well has gyro on 9/24/2008.
- 3 MIRU Slickline. Pull bumper spring and tag bottom. Record tag depth in Open Wells. RD slickline.
- 4 Prepare location for base beam equipped rig. Install perimeter fence as needed.
- 5 Check and record bradenhead pressure. If bradenhead valve is not accessible, re-plumb so that valve is above GL. Blow down bradenhead and re-check pressure the next day. Repeat until pressure stays at 0 psi.
- 6 MIRU WO rig. Spot 25 jts of 2-3/8" 4.7# J-55 tbg.
- 7 Kill well as necessary with water and biocide. Attach a hardline from the bradenhead/surface casing valve to a flowback tank and blow down any Bradenhead pressure. If pressure does not blow down within 1 hour contact engineer, otherwise proceed.
- 8 ND wellhead. NU BOP.
- 9 PU 8-10' pup joint with TIW valve on top and screw into the tbg hanger. Unseat and LD the landing joint.
- 10 MIRU EMI services. EMI 2-3/8" tbg (245 jts landed at 7753') while TOO H and tally while standing back. Lay down joints that have greater than 35% penetration or wall loss. Replace all joints that fail EMI testing. Document joint numbers and depth of bad tubing and create a Production Equipment Failure report in OpenWells. RDMO EMI services.
- 11 MIRU WL. PU and RIH with (4.5", 11.6#) Gauge Ring to 7440'. POOH.
- 12 PU and RIH with (4.5", 11.6#) CIBP. Set CIBP at +/- 7430'. POOH. SB WL.
- 13 TIH with 2-3/8" tbg to 2500'. Pumping water with biocide, pressure test CIBP and production casing to 2000 psi for 15 minutes. If test fails, contact Engineering.
- 14 TOO H and SB 2-3/8" tubing.
- 15 PU and RIH with *one* 1' 3-1/8" perf gun with 3 spf, 0.50" EHD, 120° phasing. Shoot 1' of squeeze holes at 950'. POOH. RD WL.
- 16 PU and RIH with (4.5", 11.6#) CICR on 2-3/8" tbg while hydrotesting to 4000 psi and set at 920'. Establish circulation through squeeze holes with biocide treated fresh water and circulate a minimum of 200 bbls through squeeze holes. If rate is less than 1 bpm at 1000 psi, contact engineer.
- 17 MIRU cementing services. Establish circulation and pump 20 bbl (5 bbls of water, 10 bbls of sodium silicate, and 5 bbls water) spacer, **GASBLOK cement 195 sx (227 cf) 15.8 ppg 1.16 yield. Underdisplace by 1 bbl.** (based on 30' below retainer in 4-1/2" casing, 7.88" hole size + 60% excess from 950'-685' and from 685' to 480' between 8-5/8" 24# surface casing and 4-1/2" 11.6# production casing). Attempt to cement from 950'-480'.
- 18 PUH to 750' and reverse circulate tubing clean to ensure no cement is left in the tubing. Reverse circulate until no cement in returns. TOO H. SB ALL tbg. LD stinger. WOC 24 hours.
- 19 PU and TIH with 3-7/8" bit and appropriate number of 3-1/2" drill collars on 2-3/8" tbg. Time drill cement above cement retainer (~65'). If rate of penetration is faster than 2 min/ft, SD and WOC 24 hours and repeat. Drill down to the retainer located at +/-920'. Drill retainer and cement past lower perf at 950' and pressure test to 500 psi for 5 minutes.
- 20 TOO H. SB tbg and drill collars, LD bit.
- 21 MIRU wireline and run **CCL-GR-CBL-VDL from +/- 4000' (below the original TOC) to surface.** Forward to Engineering. RDMO wireline services. In addition to normal handling, of logs/job summaries, email copies of all cement job logs/job summaries and invoices to DJVendors@anadarko.com within 24 hrs of the completion of the job.
- 22 PU and TIH with bit on 2-3/8" tubing. Drillout CIBP at 7430' and chase down to 7900'.
- 23 TOO H. SB tbg. LD drill collars and bit.

Engineer: Alex Caravaggio
213-880-8119

Retainer Suicide Squeeze (Bradenhead)

BULTHAUP 24-6

- 24 PU 2-3/8" NC, 2-3/8" XN nipple (be sure to correctly input into OpenWells), ~11 jts of 2-3/8" tbg (to set packer at 7430'), 4-1/2" Arrowset AS-1X packer (10K psi rated above and below), and 2-3/8" 4.7# J-55 tbg to surface while hydrotesting to 5000 psi. Land EOT at +/- 7770' (1 jt above Codell perfs).
- 25 Set packer at +/- 7430'. Load backside with packer fluid and test to 500 psi.
- 26 RU rig lubricator. Broach tubing to XN seating nipple. RD rig lubricator. ND BOP.
- 27 Install 7-1/16" flanged 5000 psi tubing head adaptor with studded top, 2-1/16" flanged 5000 psi master valve, flanged 5000 psi 2-3/8" plunger lubricator (side outlets threaded). Make sure all wellhead valves are rated to 5,000 psi. Document wellhead components in an OpenWells wellhead report.
- 28 Install 2-3/8" pup joint above the master valve. Pressure test the tubing head from below the tubing head through the master valve to 5,000 psi using hydrotester. If wellhead does not pressure test, replace wellhead/ wellhead valves as necessary with 5,000 psi rated equipment.
- 29 NU WH. RDMO WO rig. Return well to production team.