

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT



RECEIVED

MAR 23 98

## SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT --" for such proposals

00000

## SUBMIT IN TRIPLICATE

## 1. TYPE OF WELL

OIL ☐ WELL GAS ☐ WELL ☒ OTHER

Powder Wash Central Staging Facility

## 2. NAME OF OPERATOR

WEXPRO COMPANY

## 3. ADDRESS AND TELEPHONE NO.

P. O. BOX 458, ROCK SPRINGS, WY 82902 (307) 382-9791

## 4. LOCATION OF WELL (FOOTAGE, SEC., T., R., M., OR SURVEY DESCRIPTION)

NW NW Sec 33-T12N-R97W

5. LEASE DESIGNATION AND SERIAL NO.  
C-081267

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. IF UNIT OR CA, AGREEMENT DESIGNATION

8. WELL NAME AND NO.

Powder Wash Central Staging Fac

9. API WELL NO.

10. FIELD AND POOL, OR EXPLORATORY AREA

Powder Wash

11. COUNTY OR PARISH, STATE

Moffat, CO

## 12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

## TYPE OF SUBMISSION

☐ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

## TYPE OF ACTION

☐ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☒ Other Build Bioremediation Cell

☐ Change in Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Wexpro plans to build a bioremediation cell at the above location for future use to bioremediate oil contaminated soil from wells and facilities in the area. The cell will be operated as follows:

1. Prior to any work, a composite soil sample will be obtained from the above location and sent in for TPH analysis.
2. The main cell will be approximately 75 feet by 25 feet.

This cell will be subdivided into 3 cells that are each about 25 feet by 25 feet. The cell will be bermed to have a minimum free board of 6 inches during operation.

3. Each cell will be used once during a three year period. Example: Cell one may be used in the first year, cell two in the second year and cell three in the third year.

4. Spread and mix a layer of horse manure and sand to a depth of approximately 6 inches in each cell prior to adding any oil contaminated soil. Add contaminated soil to a total cell depth of 1-1/2 to 2 feet.

5. Mix and till cell contents to make as homogenous as possible.

6. Wet cell down weekly and till the cell monthly.

7. Add commercial fertilizer that is high in nitrogen and phosphorous or compost to each cell as needed to insure that microbes obtain all necessary nutrients to grow.

8. During the winter, any cell containing contaminated soil will be covered with a liner to increase soil temperature and not allow any chance of hydrocarbon run off.

9. Once a year soil samples will be obtained from native soil below each cell to insure no hydrocarbons are moving down.

10. Once the contaminated soil is bioremediated to a TPH below 10,000 mg/kg the soil will be spread out on locations and worked into existing soil.

14. I hereby certify that the foregoing is true and correct

Signed [Signature]

Title

OPERATIONS MANAGER

March 12, 1998

Date

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

116578