

FORM
6

Rev
12/05

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: 401268914			
Date Received:			

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: Kelsi Welch
 Name of Operator: PDC ENERGY INC Phone: (303) 831-3974
 Address: 1775 SHERMAN STREET - STE 3000 Fax: _____
 City: DENVER State: CO Zip: 80203 Email: kelsi.welch@pdce.com

For "Intent" 24 hour notice required, Name: _____ Tel: _____
 Email: _____
COGCC contact: _____

API Number 05-123-14632-00 Well Number: 3
 Well Name: LEFFLER
 Location: QtrQtr: NWNE Section: 27 Township: 6N Range: 66W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: 55630
 Field Name: BRACEWELL Field Number: 7487

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.465273 Longitude: -104.760461
 GPS Data:
 Date of Measurement: 01/21/2010 PDOP Reading: 2.1 GPS Instrument Operator's Name: Brandon Lucason
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7142	7152			
Total: 1 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	270	190	270	0	
1ST	7+7/8	3+1/2	9.2	7,302	200	7,302	6,274	

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7092 with 2 sacks cmt on top. CIBP #2: Depth 6760 with 2 sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 188 sks cmt from 646 ft. to 0 ft. Plug Type: STUB PLUG Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: 472 ft. of 3+1/2 inch casing Plugging Date: 03/06/2017

*Wireline Contractor: Ranger *Cementing Contractor: Ranger

Type of Cement and Additives Used: 15.8#/gal CI G

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Leffler 3 (05-123-14632)/Plugging Procedure (Subsequent)
Producing Formation: Codell 7142'-7152'
TD: 7343' PBSD: 7252'
Surface Casing: 8 5/8" 24# @ 270' w/ 190 sxs.
Production Casing: 3 1/2" 9.2# @ 7302' w/ 200 sks cmt. (TOC at 6274' CBL.)

Tubing: 2 1/16" tubing set at 7115'. (1/24/2013)

Proposed Procedure:

1. MIRU RU pulling unit. Pull 2 1/16" tubing.
2. RU wireline company. Run Gyro survey from 7100' to surface.
3. TIH with CIBP. Set BP at 7092'. Top with 2 sxs 15.8#/gal CI G cement.
4. TIH with CIBP. Set BP at 6760'. Top with 2 sxs 15.8#/gal CI G cement.
5. TIH with tubing to 646'. RU cementing company. Mix and pump 5 sxs 15.8#/gal CI G cement down tubing to establish stub plug.
6. TIH with casing cutter. Cut 3 1/2" casing at 472'. Pull cut casing.
7. TIH with tubing to 476'. RU cementing company. Mix and pump 183 sxs 15.8#/gal CI G cement down tubing to surface.
8. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Kelsi Welch

Title: Production Tech Date: _____ Email: kelsi.welch@pdce.com

