

WORK OVER PROCEDURE

WELLNAME: **Alles 41-31**

API # 05-123-26114

Location: 600 FNL620 FWL NENE 31 5N 63W 6th PM

SPUD DATE: 8/4/2007

SURFACE CASING SIZE: 8.625", 24#/ft Wt, Grade, 575', 12.25" hole

SURFACE CEMENT: Cemented to surface w/ 410 sx.

REMEDIAL CEMENT: NA
TD: 6733

AQUIFER DEPTH:

ORIGINAL COMPLETION

FORMATIONS:	As found in well:	Alles 41-31
	Niobrara	6312 '
	Codell	6564 '
		'

REPLUGGING PROCEDURE:

- 1) MIRU ON LOCATION. ND WH, NU BOP, RU WORK FLOOR, CONTROL WELL, TOO H WITH 2 3/8TH" TBG
- 2) TIH W/CIBP SET CIBP ~ 6275' And pressure test Casing to 1000 psi
- 3) SPOT 25 SX PLUG ON TOP OF PLUG
- 4) DETERMINE CSG STRETCH. IF CASING DOESN'T TEST SET PLUG ACROSS LEAK.
- 5) MIRU WIRELINE. SET CSG IN TENSION, TIH WITH JET CUTTER AND CUT CSG ABOVE FREE POINT 950'
- 6) TOO H W/CUT 4 1/2" CSG. LAY DOWN CSG
- 7) TIH WITH 2 3/8THS TBG AND TAG CASING STUB. STING INSIDE CSG 50'. MIRU CEMENTERS
- 8) MIRU CEMENTERS. ESTABLISH CIRCULATION, PUMP 440 SXS CEMENT TO SURFACE. TOO H, LAY DOWN TBG
- 9) ND BOP. CUT OFF BELL NIPPLE & CASING TO 4' BELOW GROUND LEVEL.
FILL TOP OF CASING WITH READY MIX
- 10) WELD ON PLATE. OPERATOR NAME, API NO., LOCATION
- 11) FILL SURFACE HOLE, MAKING SURE TO REPLACE TOP SOIL LAST
- 12) RIG DOWN AND MOVE OUT ALL EQUIPMENT