



# Integrated Production Services. JOB DATA SHEET

Company LEED Energy Services Well Name and No. SPIKE STATE GWS C24-06 Engineer Cody Fomengo  
County Weld Date 6/1/2017 Ticket No. 4310-0931 Unit No. 4310  
District Greeley CO 0928-200 Line Size 0.282 Line Length 0  
Job Time: 1:00 PM Shop Time: 7:00 AM Leave Shop: 12:00 PM Arrive Location: 12:15 PM  
Field Hrs. 2:15:00 Standby Hours: 0:00:00 Total Hours 3:05:00 Travel Time Hrs. 0:50:00  
Trip Miles 20 Leave Location: 10:25 AM Arrive Shop: 11:00 AM

**Notice: Engineer to monitor for stray voltage prior to rig up:** Wellhead volts: 0 Rig volts: 0

Were there any equipment or down hole failures? Yes      No X If yes explain on Quality Control Analysis Form  
Were there any hot shots required? Yes      No X If yes explain on Quality Control Analysis Form  
Were there any personnel problems? Yes      No X If yes explain on Quality Control Analysis Form  
Were there any accidents? Yes      No X If yes explain on Quality Control Analysis Form  
Were there any near misses? Yes      No X If yes explain on Quality Control Analysis Form

## Well Information

Casing Size 4.5 Liner Size      Tubing Size 0 Drill Pipe Size       
Drill Collar      Minimum I.D.      Fluid Level 0 Deviation       
Max. Temp.      Max. Pressure     

## Run Data

### RUN INFORMATION

### \*\*\*\*\*REMARKS SECTION\*\*\*\*\*DESCRIBE RUN DETAILS IN FULL\*\*\*\*\*

Time in	Out	Service	Remarks	Date
1 Time in <u>12:40 PM</u>	Out <u>1:30 PM</u>	From <u>SURFACE</u> To <u>6709</u>	RIH with CIBP, set@6709', POOH	30-May
Service <u>CIBP(set@6709')</u>				
2 Time in <u>12:30 PM</u>	Out <u>12:55 PM</u>	From <u>SURFACE</u> To <u>2550</u>	RIH with CIBP, set@2550', POOH	1-Jun
Service <u>CIBP(set@2550)</u>				
3 Time in <u>1:00 PM</u>	Out <u>1:15 PM</u>	From <u>SURFACE</u> To <u>2500</u>	RIH with Squeeze Gun, shot holes@2500', POOH	1-Jun
Service <u>Squeeze Gun(holes@2500')</u>				
4 Time in <u>1:20 PM</u>	Out <u>1:35 PM</u>	From <u>SURFACE</u> To <u>2416</u>	RIH with CICR, set@2416', POOH	1-Jun
Service <u>CICR(set@2416')</u>				
5 Time in <u>10:00 AM</u>	Out <u>10:05 AM</u>	From <u>SURFACE</u> To <u>560'</u>	RIH with Jet Cutter, cut Casing@560'	2-Jun
Service <u>Jet Cutter(cut Casing@ 560</u>				
6 Time in <u>12:00 AM</u>	Out <u>12:00 AM</u>	From <u>0</u> To <u>0</u>		
Service <u>0</u>				
7 Time in <u>    </u>	Out <u>    </u>	From <u>    </u> To <u>    </u>		
Service <u>    </u>				
8 Time in <u>    </u>	Out <u>    </u>	From <u>    </u> To <u>    </u>		
Service <u>    </u>				