



SRC ENERGY

**Operator:** SRC Energy  
**Well Name:** Wolfson #26-16  
**Legal:** SESE, Section 26, Township 4N, Range 67W  
**Location:** Weld County, CO  
**API:** 05-123-14511  
**Surface:** 8.625" 24# @ 232'                      **Hole Size:** 12.25"                      **TOC:** Surface  
**Production:** 4.5" 11.6# @ 7,367'                      **Hole Size:** 7.875"                      **TOC:** 6,150 (CBL)  
**Perforations:** 6889' – 7212' (Niobrara-Codell)  
**TD:** 7,373'

#### P&A Procedure

1. Conduct pre-job safety meeting and complete daily JSA
2. Blow down well if necessary, circulate hole with treated water
3. Dig out around wellhead and check surface annulus for pressure
4. MIRU WO unit, ND wellhead, NU BOP, tally all pipe out of the hole
5. RIH w/ 4-1/2", 11.6# CIBP, set at 6,810' and pump 12 sxs on top to create 120' plug, reverse circulate and TOOH with tubing
6. RIH perforate circulation holes @ 4700' and RIH perforate holes 4300', RIH w/ 4-1/2", 11.6# retainer, set at 4325'.
7. TIH w/ tbg and pump circulation squeeze, 78 sxs, thru retainer, spot 3 sxs above, reverse circulate and TOOH with tubing
8. Pressure test csg to 500 psi for 15 minutes
9. Cut 4.5" @ 282' and POOH
10. TIH to 332' and pump a shoe plug:
  - a. 150 sxs of 15.8# class G neat 1.15 cu./ft. yield cement
  - b. Pull into surface casing, reverse circulate
  - c. Wait 4 hours and tag plug
11. RDMO WO unit
12. Dig up wellhead and cut off 10' below restored ground level, top off if necessary
13. Weld on cap with ID plate, inscribed with well location, and identity
14. Backfill, clean location
15. P&A complete