

**FORM**  
**6**

Rev  
12/05

**State of Colorado**  
**Oil and Gas Conservation Commission**

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number:  401459967			
Date Received:			

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: <u>69175</u>	Contact Name: <u>Jenifer Hakkarinen</u>
Name of Operator: <u>PDC ENERGY INC</u>	Phone: <u>(303) 8605800</u>
Address: <u>1775 SHERMAN STREET - STE 3000</u>	Fax: _____
City: <u>DENVER</u> State: <u>CO</u> Zip: <u>80203</u>	Email: <u>Jenifer.Hakkarinen@pdce.com</u>
<b>For "Intent" 24 hour notice required,</b> Name: <u>Pesicka, Conor</u> Tel: <u>(970) 415-0789</u>	
<b>COGCC contact:</b> Email: <u>conor.pesicka@state.co.us</u>	

API Number <u>05-123-24085-00</u>	Well Number: <u>12-2</u>
Well Name: <u>BROWN</u>	
Location: QtrQtr: <u>SWNW</u> Section: <u>2</u> Township: <u>6N</u> Range: <u>63W</u> Meridian: <u>6</u>	
County: <u>WELD</u> Federal, Indian or State Lease Number: _____	
Field Name: <u>WATTENBERG</u> Field Number: <u>90750</u>	

Notice of Intent to Abandon       Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.518140 Longitude: -104.410110

GPS Data:  
Date of Measurement: 10/05/2006 PDOP Reading: 2.1 GPS Instrument Operator's Name: H.L.TRACY

Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_

Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_

Fish in Hole:  Yes  No If yes, explain details below

Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below

Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	6736	6744			
NIOBRARA	6506	6572			
Total: 2 zone(s)					

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	439	225	439	0	VISU
1ST	7+7/8	4+1/2	10.5	6,962	680	6,962	390	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6456 with 2 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 60 sks cmt from 650 ft. to 0 ft. Plug Type: CASING Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Perforate and squeeze at 390 ft. with 90 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)  
 Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

Brown 12-2 (05-123-24085)/Plugging Procedure (Intent)  
 Producing Formation (Perforations): Niobrara: 6506'-6572' Codell: 6736'-6744'  
 TD: 6991' PBTD: 6921'  
 Surface Casing: 8 5/8" 24# @ 439' w/ 225 sxs  
 Production Casing: 4 1/2" 10.5# @ 6962' w/ 680 sxs cmt (TOC @ 390' - CBL).  
 Tubing: 2 3/8" tubing set @ 6721' (10/2/2015).  
 Proposed Procedure:  
 1. Run gyro survey.  
 2. MIRU pulling unit. Pull 2 3/8" tubing.  
 3. RU wireline company.  
 4. TIH with CIBP. Set BP at 6456'. Top with 2 sxs 15.8#/gal CI G cement.  
 5. TIH with perforation gun. Shoot 2 holes for annular squeeze at 390' @ 1 SPF or preferred.  
 6. TIH with tubing to 650'. RU cementing company. Mix and pump 60 sxs 15.8#/gal CI G cement down tubing. Cement should circulate to surface. TOOH with tubing.  
 7. Hook up cement line to cement flange and pump 90 sxs 15.8#/gal CI G cement into annular space. Cement should circulate to surface.  
 8. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: JEnifer Hakkarinen  
 Title: Reg TEch Date: \_\_\_\_\_ Email: Jenifer.Hakkarinen@pdce.com

