



SRC ENERGY

**Operator:** SRC Energy  
**Well Name:** Tigges 18-11  
**Legal:** NENE, Section 18, Township 6N, Range 66W  
**Location:** Weld County, CO  
**API:** 05-123-25583  
**Surface:** 8.625" 24# @ 651' **Hole Size:** 12.25" **TOC:** Surface  
**Production:** 4.5" 11.6# @ 7,345' **Hole Size:** 7.875" **TOC:** 225' (CBL)  
**Perforations:** 7,234' – 7,250' (Codell)  
**TD:** 7,364'

P&A Procedure

1. Conduct pre-job safety meeting and complete daily JSA
2. Blow down well if necessary, circulate hole with treated water
3. Dig out around wellhead and perform bradenhead test
4. MIRU WO unit, ND wellhead, NU BOP, tally all pipe
5. TIH w/ 4-1/2 11.6# CIBP, set at 7159'
6. Pressure test casing to 500 psi for 15 minutes
7. Set 45 sx on top of CIBP (cover 200' above Niobrara top)
8. TIH to 4500' and pump Sussex plug (300' plug)
  - a. Pump 29 sx to create casing plug (4200' – 4500')
9. Cut 4.5" production casing @ 200' and POOH
10. TIH to 801' and pump stub plug (0' – 801')
  - a. 136 sx of 15.8# class G neat 1.15 cu./ft. yield cement
  - b. 150' out of surface casing
  - c. Wait 4 hours and tag plug
11. RDMO WO unit
12. Dig up wellhead and cut off 10' below restored ground level, top off if necessary
13. Weld on cap with ID plate, inscribed with well location, and identity
14. Backfill, clean location
15. P&A complete