

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total:

PROCEDURE FOR HILL 6-1

1. POOH WITH TUBING
2. MIRU WIRELINE, RIH SET CIBP @ 6900, THEN DUMP BAIL 2 SX CEMENT ON PLUG
3. RIH WITH TBG TO 6870', LOAD HOLE WITH 9 PPG MUD,
4. PRESSURE TEST CSG TO 500 PSI AND HOLD
5. POOH WITH TBG,
6. RIG UP WIRELINE, AND PERF SQZ HOLES AT 5800'
7. RIH WITH TBG TO 5600', MIX AND PUMP 20 SX CLASS C CEMENT PLUG LEAVING CMT INSIDE CASING FROM 5800-5649
8. WOC AND TAG
9. POOH WITH TBG, RIG UP WIRELINE
10. RIH AND PERF AT 1500'
11. RIH WITH TBG, MIX AND PUMP 20 SX PLUG LEAVING CEMENT INSIDE CSG 1500-1349'
12. WOC AND TAG
13. POOH WITH TBG , RIG UP WIRELINE, AND PERF AT 530'
14. MIX AND PUMP 140 SX CMT, PUMP DOWN CSG, TAKING RETURNS UP SURF/PROD CSG ANNULUS UNTIL CEMENT SEEN AT SURFACE. THIS LEAVES CEMENT FROM SURFACE TO 530' IN/OUT OF PROD CSG.
15. CUT OFF WELLHEAD AND CSG PER COGCC RULES. PLATE AND ID CSG.